

LS006-002-2H
LUNAR ROVING VEHICLE
OPERATIONS HANDBOOK

STA/STEP	PROCEDURE	REMARKS
2.3.2	(Continued)	
g.	Connect GCTA connector of LRV/LCRU cable to GCTA control unit.	
h.	On TV camera, LM PWR Switch - OFF.	
i.	Disconnect LM/TV cable from TV camera and rest connector on tripod handle.	
j.	Remove TV camera from LM tripod and install on GCTA azimuth/elevation unit.	
k.	Connect GCTA control unit connector to TV camera.	
2.3.3	16 mm Data Acquisition Camera Installation	Figure 2-14.
a.	Remove camera and staff from LM.	
b.	Assemble camera and staff into single unit.	
c.	Insert staff into receptacle on LRV right inboard handhold.	
d.	Verify staff locked in place by pulling up on the camera without depressing the push button on end of handhold. Camera staff should not move vertically.	
2.3.4	Low Gain Antenna Installation	Figure 2-14.
a.	Remove low gain antenna from LM stowage location.	
b.	Insert low gain antenna staff on LRV left inboard handhold.	
c.	Verify staff locked in vertically by pulling up on staff without depressing button on end of handhold. Low gain antenna staff should not move vertically.	

LS006-002-2H
LUNAR ROVING VEHICLE
OPERATIONS HANDBOOK




FIGURE 2-14 16 MM DAC AND LOW GAIN ANTENNA INSTALLATION

LS006-002-2H
LUNAR ROVING VEHICLE
OPERATIONS HANDBOOK

STA/STEP	PROCEDURE	REMARKS
2.3.4	(Continued)	Figure 2-15.
d.	Route low gain antenna cable to LCRU and secure to LRV with strap on console and clips on forward chassis.	
e.	Connect low gain antenna cable to LCRU.	
2.3.5	High Gain Antenna Installation.	Figure 2-13.
a.	Remove high gain antenna from LM stowage position.	
b.	Insert high gain antenna staff into the mounting receptacle on the left front corner of the LRV and lock.	Alignment marks are provided on HGA staff locking collar.
c.	Unfold and lock HGA staff.	
d.	Remove and discard optical sight retaining clamp.	
e.	Open and lock HGA dish.	
f.	Connect HGA cable to the LCRU.	
g.	Activate LCRU/GCTA and perform communication checks as required.	
h.	Deactivate LCRU/GCTA until needed.	
2.3.6	Aft Payload Pallet Installation	Figure 2-16.
a.	Release the pallet support post tiedown on LRV aft chassis.	
b.	Erect pallet support post.	
c.	Remove pallet from LM.	

LS006-002-2H
LUNAR ROVING VEHICLE
OPERATIONS HANDBOOK




FIGURE 2-15 LCRU LOW GAIN ANTENNA CABLE INSTALLATION ON LUNAR SURFACE




FIGURE 2-16 LRV REAR PAYLOAD PALLET ADAPTERS

15006-002-2H
 LUNAR ROVING VEHICLE
 OPERATIONS HANDBOOK

STA/STEP	PROCEDURE	REMARKS
2.3.6 (Continued)	d. Connect pallet to pallet support post.	
e.	Rotate pallet about support post until pallet locks in pallet adapter on LRV LH aft chassis.	Figure 2-17.
2.3.7	Buddy SLSS Installation	
a.	Remove BSLSS bag from LM.	
b.	Release BSLSS support strap on back of right seat.	
c.	Feed strap through BSLSS bag handle and secure to PLSS support velcro on front of back seat.	Figure 2-18.




FIGURE 2-17 REAR PAYLOAD PALLET INSTALLED

LS006-002-2H
LUNAR ROVING VEHICLE
OPERATIONS HANDBOOK




FIGURE 2-18 BUDDY SLSS INSTALLATION

LS006-002-2H
LUNAR ROVING VEHICLE
OPERATIONS HANDBOOK

STA/STEP	PROCEDURE	REMARKS
2.4	<p>PRE SORTIE CHECKOUT AND PREPARATION</p> <p>a. Verify battery and SPU dust covers closed.</p> <p>b. Verify hand controller in parking brake and neutral throttle position and reverse inhibit switch is on (pushed down).</p> <p style="text-align: center;">CAUTION</p> <p>Do not grasp the 16 MM Data Acquisition camera staff or low gain antenna staff during ingress. The handholds are designed for ingress by grasping the handhold horizontal and vertical members below the payload staffs.</p> <p>c. LRV driver ingress LRV left seat and fasten seat belt.</p> <p>d. Other crewman ingress LRV, and fasten seat belt.</p> <p style="text-align: center;">CAUTION</p> <p>Do not grasp the 16 MM Data Acquisition camera staff or low gain antenna staff during ingress. The handholds are designed for ingress by grasping the handhold horizontal and vertical members below the payload staffs.</p> <p>NOTE: If this is the first LRV sortie and this procedure sequence immediately follows initial payload loading (2.3) and LRV post deployment checkout (2.2), then at this point the C/D panel is in a power down configuration in accordance with step 2.2.ad. If this is the case then step 2.4 need only be a verification as it has been previously accomplished.</p>	<p>Board left seat first and verify parking brake set prior to other crewman boarding. Do not board both seats simultaneously.</p>

LS006-002-2H
LUNAR ROVING VEHICLE
OPERATIONS HANDBOOK

STA/STEP	PROCEDURE	REMARKS
2.4	(Continued)	
e.	BUS A, BUS B, BUS C, BUS D CB's - Close.	
f.	NAV POWER CB - Close. <div data-bbox="321 1191 384 1440" style="border: 2px dashed black; padding: 2px; text-align: center; width: fit-content; margin: 0 auto;">CAUTION</div> Do not torque nav gyro until nav power has been on for 3 minutes.	Nav gyro is allowed to warm up and stabilize during payload loading.
g.	Report BAT 1 and BAT 2 AMPS.	
h.	BATTERY Switch - VOLTX x 1/2.	
i.	Report BAT 1 and BAT 2 VOLTS.	
j.	Report BAT 1 and BAT 2 AMP-HR. Insure reading is stabilized, indicating the amp-hr integrator has had adequate warmup time.	
k.	BATTERY Switch - AMPS.	
l.	DRIVE ENABLE LF and RF Switches - PWM 1.	
m.	DRIVE ENABLE LR and RR Switches - PWM 2.	
n.	+ 15 VDC Switch - PRIM.	
o.	STEERING FORWARD Switch - BUS A.	Forward steering operates from Battery No. 1.
p.	STEERING REAR Switch - BUS D. <div data-bbox="964 1170 1027 1419" style="border: 2px dashed black; padding: 2px; text-align: center; width: fit-content; margin: 0 auto;">CAUTION</div> The hand controller should be in park brake position and the drive enable switches must be set to an active PWM prior to setting any drive power switch to an energized bus. If the drive power switch is turned on and	Rear steering operates from Battery No. 2. The PWM select switch determines which PWM is active. The hand controller was verified in park brake position in step 2.2.ac.

LS006-002-2H
LUNAR ROVING VEHICLE
OPERATIONS HANDBOOK

STA/STEP	PROCEDURE	REMARKS
2.4	(Continued)	The PWM select switch was verified in "BOTH" position in step 2.2.b. The drive enable switches were set to active PWM positions in steps 2.4.1 and 2.4.m.
	CAUTION (Continued)	Front wheels operate from Battery No. 1. Rear wheels operate from Battery No. 2.
q.	DRIVE POWER LF Switch - BUS A.	
r.	DRIVE POWER RF Switch - BUS A.	
s.	DRIVE POWER LR Switch - BUS D.	
t.	DRIVE POWER RR Switch - BUS D.	
u.	Drive LRV to level area ($\pm 6^\circ$ pitch) near the LM.	
v.	Deploy SUN SHADOW DEVICE (SSD).	
w.	Deploy Vehicle Attitude Indicator to read roll.	
x.	Park down sun (within $\pm 3^\circ$ per SSD) and level (within $\pm 6^\circ$ roll) and set brake.	
y.	Report sun shadow device readings and LRV pitch and roll angles.	
z.	Fold (or reset) Sun Shadow Device (SSD).	Reset SSD to prevent it from obstructing drivers access to system reset switch.

LS006-002-2H
LUNAR ROVING VEHICLE
OPERATIONS HANDBOOK

STA/STEP	PROCEDURE	REMARKS
2.4	<p>(Continued)</p> <p>aa. Fold Vehicle Attitude Indicator to drive position (pitch read position).</p> <p>al. Pull system reset switch from detent move momentarily to reset position and return to off.</p> <p>ac. Verify BEARING, DISTANCE, RANGE Indicators - ZERO.</p> <p>ad. Receive calculated heading from MCC.</p> <div style="text-align: center; border: 2px dashed black; padding: 5px; width: fit-content; margin: 10px auto;"> CAUTION </div> <p>Continuous torquing of nav gyro shall not exceed 2 minutes of any 7 minute period.</p> <p>ae. Pull GYRO TORQUING Switch from detent and operate to LEFT or RIGHT for proper heading indication, then OFF.</p> <p>af. Report battery 1 and 2 Amp-Hrs.</p> <p>ag. Report battery and drive motor temperatures.</p> <p>ah. Report battery current while vehicle is in motion one time between stops.</p>	<p>Torque LEFT causes heading indication to move CCW. Torque RIGHT causes heading indication to move CW.</p>

LS006-002-2H
 LUNAR ROVING VEHICLE
 OPERATIONS HANDBOOK

STA/STEP	PROCEDURE	REMARKS
2.5	<p>LRV CONFIGURATION FOR SCIENCE STOP</p> <p>a. Stop LRV and set hand controller in parking brake position; Neutral throttle.</p> <p>b. Perform LRV partial power down as follows:</p> <p>DRIVE POWER Switches (4) - OFF. STEERING Switches (2) - OFF. + 15 VEC Switch - OFF.</p> <p>c. Report BEARING, DISTANCE, RANGE, HEADING, and BATTERY AMP-HOUR indications.</p> <p>d. Crewman in right seat release and stow seat belt and egress vehicle.</p> <p>e. Crewman in left seat release and stow seat belt and egress vehicle.</p> <p>f. Align HGA.</p> <p>g. LCRU mode Switch - FM/TV or TV RMT.</p> <p>h. Open LCRU thermal blanket per ground request.</p>	<p>See remarks for step 2.2.ac.</p> <p>TV RMT will provide improved TV performance when the LM is available for voice relay.</p>

LS006-002-2H
LUNAR ROVING VEHICLE
OPERATIONS HANDBOOK

STA/STEP	PROCEDURE	REMARKS
2.6	<p>LRV CONFIGURATION PRIOR TO LEAVING SCIENCE STOP</p> <ol style="list-style-type: none"> a. Align LGA. b. LCRU Mode Switch - PM1/WB. c. Board LRV left seat and fasten seatbelt. <div style="border: 2px dashed black; padding: 2px; text-align: center; margin: 5px 0;">CAUTION</div> <p>Do not grasp the 16 MM Data Acquisition camera staff or low gain antenna staff during ingress. The handholds are designed for ingress by grasping the handhold horizontal and vertical members below the payload staffs.</p> d. Verify hand controller in parking brake and neutral throttle position and reverse inhibit switch is on (pushed down). e. Other crewman ingress LRV right seat and fasten seat belt. <div style="border: 2px dashed black; padding: 2px; text-align: center; margin: 5px 0;">CAUTION</div> <p>Do not grasp the 16 MM Data Acquisition camera staff or low gain antenna staff during ingress. The handholds are designed for ingress by grasping the handhold horizontal and vertical members below the payload staffs.</p> f. Report Bearing, Distance, Range, Heading, and Battery Amp-Hour indications. g. Update Nav System to correct for drift, if required by MCC. h. + 15 VDC Switch - PRIM. 	

LS006-002-2H
 LUNAR ROVING VEHICLE
 OPERATIONS HANDBOOK

STA/STEP	PROCEDURE	REMARKS
2.6	(Continued)	
i.	STEERING FORWARD Switch - BUS A.	
j.	STEERING REAR Switch - BUS D.	
	<p style="text-align: center;">CAUTION</p> <p>The hand controller should be in park brake position and the drive enable switches must be set to an active PWM prior to setting any drive power switch to an energized bus. If the drive power switch is turned on and the corresponding drive enable switch is not selected to an active PWM, then full power will be applied to the corresponding drive motor when the hand controller is released from brake position. Should this condition occur the hand controller should be immediately returned to park brake position.</p>	<p>The PWM select switch determines which PWM is active. The hand controller was verified set in park brake position in step 2.6.d. The PWM select switch was verified in "BOTH" position in step 2.2.b. The drive enable switches were set to active PWM positions in steps 2.2.p and 2.2.q.</p>
k.	DRIVE POWER LF Switch - BUS A.	
l.	DRIVE POWER RF Switch - BUS A.	
m.	DRIVE POWER LR Switch - BUS D.	
n.	DRIVE POWER RR Switch - BUS D.	

LS006-002-2H
LUNAR ROVING VEHICLE
OPERATIONS HANDBOOK

STA/STEP	PROCEDURE	REMARKS
2.7	<p>POST SORTIE CHECKOUT</p> <ol style="list-style-type: none"> a. Park LRV cross sun from the right in view of LM windows. b. Hand controller in parking brake position, throttle in neutral - SET BRAKE. c. Report BEARING, DISTANCE, and RANGE. d. Report BAT 1 and BAT 2 AMP-HR. e. Report BAT 1 and BAT 2 VOLTS. f. BATTERY Switch - AMPS. g. Report battery and drive motor temperatures. h. DRIVE POWER Switches (4) - OFF. i. STEERING Switches (2) - OFF. j. + 15 VDC Switch - OFF. k. Nav Power Circuit Breaker - OPEN. l. BUS A, BUS B, BUS C, BUS D Circuit Breakers - OPEN. m. Crewman in right seat release and stow seat belts and egress LRV. n. Crewman in left seat release and stow seat belts and egress LRV. o. Align HGA. p. LCRU mode Switch - TV RMT. 	Figure 5-2.

LS006-002-2H
LUNAR ROVING VEHICLE
OPERATIONS HANDBOOK

STA/STEP	PROCEDURE	REMARKS
2.7	(Continued)	
q.	Open LRV Battery and SPU Dust Covers.	
r.	<u>Prior to LM Ingress</u> - Perform the following: LCRU Power Switch - OFF. Adjust LCRU Thermal Blankets per ground request.	

SECTION 3

MALFUNCTION PROCEDURES

3.0 INTRODUCTION

Malfunction procedures encompass the recognition, diagnosis, and corrective action for system malfunctions. In most cases, the crew is alerted to a malfunction condition by Control and Display Panel meters or indicators. The crew will then locate, correct, or isolate the malfunction and determine its effect on the scheduled mission. In general, the procedures cover significant single failures. Double unrelated failures are not covered to prevent procedures from becoming complex and unmanageable. Malfunctions of a minor nature not requiring detailed procedures are covered in Section 2.

The malfunction procedures are arranged in logic flow diagram format and arranged by symptom routine. A three column format is used for symptom routine logic flow diagrams. A description and use of each of these columns is as follows.

3.1 SYMPTOM COLUMN

The primary purpose of the symptom column is to allow entry into the malfunction procedures. This block explains and qualifies the situation so that the reader understands the symptom or condition that exists. All symptoms are numbered in sequence starting with the number 1.

3.2 PROCEDURE COLUMN

The procedure column presents a step-by-step logic flow diagram of actions and decisions used to isolate or correct a malfunction symptom. This information is presented with several types of logic blocks. These blocks contain the procedures, decisions, and actions to locate and isolate the failure. Remote event symbols are used to reference items in the remarks column or to refer to other procedural steps.

3.3 REMARKS COLUMN

This column will include the following information:

- Amplifying additional remarks related to the symptom.
- Amplifying remarks which relate to a decision and/or action items (e.g., why a step is taken, etc.)
- Explain resultant system status or operational capability after a failure has been identified, i.e., how subsystem is degraded, can degraded subsystem support primary mission, early termination of mission, etc.
- Cautions or warnings, as necessary, to cover conditions that may exist because of a failure.

LS006-002-2H
LUNAR ROVING VEHICLE
OPERATIONS HANDBOOK

<u>MALFUNCTION PROCEDURES</u>	<u>NO.</u>	<u>PAGE</u>
CAUTION AND WARNING FLAG ACTUATES	1	3-3
EITHER BATTERY TEMP > 125°F	2	3-3
ONE DRIVE MOTOR TEMP > 400°F	3	3-4
ABNORMAL IMBALANCE BETWEEN BAT 1 AND BAT 2 AMPS (VEHICLE ACCELERATION NORMAL OR LOW)	4	3-4
FRONT (REAR) WHEELS DO NOT RESPOND TO HAND CONTROLLER STEERING COMMANDS	5	3-5
ONE OR MORE WHEELS DRIVE WHILE IN NEUTRAL	6	3-6
LOSS OF DRIVE FROM ONE OR TWO WHEELS (COMMANDED ACCELERATION ABNORMALLY LOW)	7	3-7
COMMANDED VEHICLE SPEED ABNORMALLY HIGH (SPEED NOT VARIABLE ON ONE OR MORE WHEELS)	8	3-8
LOSS OF DRIVE FROM ALL WHEELS	9	3-9
BRAKE WILL NOT RELEASE	10	3-10
LOSS OF VOICE COMM WITH MSFN	11	3-11

TABLE 3-1 MALFUNCTION PROCEDURES

L5006-002-211
LUNAR ROVING VEHICLE
OPERATIONS HANDBOOK

SYMPTOM	PROCEDURE	REMARKS
<p>1</p> <p>CAUTION AND WARNING FLAG ACTUATES</p>	<pre> graph TD S1[1] --> P1[1] P1 --> P2{2} P2 -- YES --> S2[2] P2 -- YES --> S3[3-3] P2 -- NO --> P3{3} P3 -- YES --> S3_4[3 3-4] P3 -- NO --> P4[4] P4 --> R1[1] </pre>	<p>1</p> <p>IF C&W FLAG CONTINUES TO ACTUATE OR WILL NOT RESET, LEAVE FLAG UP AND IGNORE IT.</p>
<p>2</p> <p>EITHER BATTERY TEMP >125°F</p>	<pre> graph TD S2[EITHER BATTERY TEMP >125°F] --> P1{1} P1 -- YES --> P2[2] P1 -- NO --> S4_34[SYMPTOM 4 3-4] P2 --> P3[3] P3 --> R1[1] P3 --> S1_3[1] P3 --> S2_3[2] P3 --> S3_3[3] P3 --> S4_3[4] P3 --> S5_3[5] P3 --> S6_3[6] P3 --> S7_3[7] P3 --> S8_3[8] P3 --> S9_3[9] P3 --> S10_3[10] P3 --> S11_3[11] P3 --> S12_3[12] P3 --> S13_3[13] P3 --> S14_3[14] P3 --> S15_3[15] P3 --> S16_3[16] P3 --> S17_3[17] P3 --> S18_3[18] P3 --> S19_3[19] P3 --> S20_3[20] P3 --> S21_3[21] P3 --> S22_3[22] P3 --> S23_3[23] P3 --> S24_3[24] P3 --> S25_3[25] P3 --> S26_3[26] P3 --> S27_3[27] P3 --> S28_3[28] P3 --> S29_3[29] P3 --> S30_3[30] P3 --> S31_3[31] P3 --> S32_3[32] P3 --> S33_3[33] P3 --> S34_3[34] P3 --> S35_3[35] P3 --> S36_3[36] P3 --> S37_3[37] P3 --> S38_3[38] P3 --> S39_3[39] P3 --> S40_3[40] P3 --> S41_3[41] P3 --> S42_3[42] P3 --> S43_3[43] P3 --> S44_3[44] P3 --> S45_3[45] P3 --> S46_3[46] P3 --> S47_3[47] P3 --> S48_3[48] P3 --> S49_3[49] P3 --> S50_3[50] P3 --> S51_3[51] P3 --> S52_3[52] P3 --> S53_3[53] P3 --> S54_3[54] P3 --> S55_3[55] P3 --> S56_3[56] P3 --> S57_3[57] P3 --> S58_3[58] P3 --> S59_3[59] P3 --> S60_3[60] P3 --> S61_3[61] P3 --> S62_3[62] P3 --> S63_3[63] P3 --> S64_3[64] P3 --> S65_3[65] P3 --> S66_3[66] P3 --> S67_3[67] P3 --> S68_3[68] P3 --> S69_3[69] P3 --> S70_3[70] P3 --> S71_3[71] P3 --> S72_3[72] P3 --> S73_3[73] P3 --> S74_3[74] P3 --> S75_3[75] P3 --> S76_3[76] P3 --> S77_3[77] P3 --> S78_3[78] P3 --> S79_3[79] P3 --> S80_3[80] P3 --> S81_3[81] P3 --> S82_3[82] P3 --> S83_3[83] P3 --> S84_3[84] P3 --> S85_3[85] P3 --> S86_3[86] P3 --> S87_3[87] P3 --> S88_3[88] P3 --> S89_3[89] P3 --> S90_3[90] P3 --> S91_3[91] P3 --> S92_3[92] P3 --> S93_3[93] P3 --> S94_3[94] P3 --> S95_3[95] P3 --> S96_3[96] P3 --> S97_3[97] P3 --> S98_3[98] P3 --> S99_3[99] P3 --> S100_3[100] </pre>	<p>1</p> <p>ALL CKT BREAKERS SHOULD REMAIN CLOSED. BATTERY COVERS WILL AUTOMATICALLY CLOSE WHEN PROPER TEMP LEVELS ARE REACHED.</p> <p>2</p> <p>COOLDOWN RATE IN ACCORDANCE WITH APPENDIX A.</p> <p>3</p> <p>BATTERY MAY BE UTILIZED WHEN TEMPERATURE PERMITS</p> <p>4</p> <p>DISREGARD TEMPERATURE INDICATION. MONITOR A-H, VOLTS/AMPS.</p> <p>5</p> <p>DEGRADED MISSION.</p>
SYMPTOM	PROCEDURE	REMARKS

TABLE 3-2. MALFUNCTION LOGIC FLOW DIAGRAM

LS006-002-211
LUNAR ROVING VEHICLE
OPERATIONS HANDBOOK

SYMPTOM	PROCEDURE	REMARKS
<p>3</p> <p>ONE DRIVE MOTOR TEMP >400°F</p>	<pre> graph TD S1[1 STOP VEHICLE FOR AFFECTED WHEEL: - DRIVE PWR OFF - DRIVE ENABLE OFF] --> S2[2 DECOUPLE AFFECTED WHEEL, RESUME SORTIE] S2 --> S3[3 MOTOR TEMP INDICATE GRADUAL COOLDOWN?] S3 -- YES --> S4[4 MOTOR THERMAL CAPABILITY DE-GRADED] S3 -- NO --> S5[5 MOTOR TEMP SENSOR FAILURE] </pre>	<p>1 DRIVE AND BRAKING IN ACCORDANCE WITH APPENDIX A. IF WHEEL IS R.R., SPEED METER WILL NOT FUNCTION.</p> <p>2 IF REQUIRED, WHEEL CAN BE RECOUPLED WHEN TEMP. PERMITS.</p> <p>3 WHEEL CAN BE RECOUPLED AT CREW OPTION. TEMP INDICATION SHOULD BE DISREGARDED.</p>
<p>4.</p> <p>ABNORMAL IMBALANCE BETWEEN BAT 1 AND BAT 2 AMPS (VEHICLE ACCELERATION NORMAL OR LOW)</p>	<pre> graph TD S1[1 ONE AT A TIME: DRIVE POWER SWITCHES (4) OFF, THEN ORIGINAL POSITION] --> Q1{AMPS RETURN TO NORMAL WITH ANY DRIVE POWER SWITCH OFF?} Q1 -- YES --> S2[2 SHORT IN DRIVE MOTOR OR DRIVE PWR CIRCUITRY] Q1 -- NO --> S3[4 DRIVE ENABLE SWITCHES (4) - PWM 1] S3 --> Q2{AMPS NORMAL?} Q2 -- YES --> S4[5 PWM 2 FAILURE] Q2 -- NO --> S5[7 DRIVE ENABLE SWITCHES (4) - PWM 2] S5 --> Q3{AMPS NORMAL?} Q3 -- YES --> S6[8 PWM 1 FAILURE] Q3 -- NO --> S7[6 PWM SELECT SWITCH - PWM 1] S7 --> S8[9 PWM SELECT SW - PWM 2] S8 --> S9[10] </pre>	<p>1 IF ABNORMAL CONDITION EXISTS ONLY WHEN LRV IS IN MOTION, THIS STEP MUST BE PERFORMED WITH LRV IN MOTION</p> <p>2 DO NOT ALLOW DRIVE ENABLE SWITCH TO REMAIN IN "OFF" POSITION WHILE SWITCHING, OR FULL POWER TO AFFECTED MOTOR WILL RESULT.</p>
SYMPTOM	PROCEDURE	REMARKS

TABLE 3-2. MALFUNCTION LOGIC FLOW DIAGRAM (CONTINUED)

SYMPTOM	PROCEDURE	REMARKS
<p>4 (CONTINUED)</p>	<pre> graph TD 7[7] --> 10[10 DR PWP SW (4) - ALTERNATE POSITION AMPS NORMAL?] 10 -- YES --> 12[12 OPEN IN DRIVE MOTOR POWER CIRCUITRY FOR ONE BUS] 10 -- NO --> 11[11 PROBABLE OPEN IN DRIVE MOTOR POWER CIRCUITRY] 11 --> 13[13 DR PWR SW (4) - OFF, THEN BACK TO ORIGINAL POSITION ONE AT A TIME TO ISOLATE MOTOR NOT DRAWING AMPS] 13 --> 14{14 FAILED MOTOR ISOLATED?} 14 -- YES --> 15[15 AFFECTED WHEEL: - DRIVE PWR SW - OFF - DRIVE ENABLE SW - OFF - DECOUPLE WHEEL] 14 -- NO --> 14 14 --> 14 </pre>	
<p>5</p> <p>FRONT (REAR) WHEELS DO NOT RESPOND TO HAND CONTROLLER STEERING COMMANDS</p>	<pre> graph TD 1[1 FORWARD (REAR) STEERING SWITCH - ALTERNATE POSITION] --> 2{2 DO FRONT (REAR) WHEELS RESPOND TO HAND CONTROLLER?} 2 -- YES --> 2[2 LOSS OF FORWARD (REAR) REDUNDANT STEERING CIRCUIT] 2 -- NO --> 3[3 FORWARD (REAR) STEERING INOP] 3 --> 4[4 FORWARD (REAR) STEERING SWITCH - OFF - DECOUPLE FWD (REAR) STEERING - CENTER & LOCK FWD (REAR) WHEELS] </pre>	<p>① TO REDUCE REQUIRED FORCE, STRAIGHTEN WHEELS BY PUSHING ON WHEEL WITH SMALLER TURNING ANGLE, (I.E. IF WHEELS ARE TURNED TO RIGHT, PUSH ON LEFT WHEEL TO STRAIGHTEN).</p> <ul style="list-style-type: none"> - HAND TOOL PRY FORCE MAY BE REQUIRED - SIMULTANEOUS PULL FORCE MAY BE REQUIRED ON DECOUPLING RING <p>DEGRADED OPERATION - STEERING RADIUS INCREASED IN ACCORDANCE WITH APPENDIX A</p>
SYMPTOM	PROCEDURE	REMARKS

TABLE 3-2. MALFUNCTION LOGIC FLOW DIAGRAM (CONTINUED)

LS006-002-2H
LUNAR ROVING VEHICLE
OPERATIONS HANDBOOK

SYMPTOM	PROCEDURE	REMARKS
<p>6</p> <p>ONE OR MORE WHEELS DRIVE WHILE IN NEUTRAL</p>	<pre> graph TD S1[1 STOP LRV DRIVE ENABLE SW (4) - PWM 1] -- YES --> B1[2 PWM 2 OUTPUT CIRCUITRY OR DRIVE ENABLE SWITCH FAILURE] S1 -- NO --> S2[3 DRIVE ENABLE SW (4) - PWM 2] S2 -- YES --> B2[4 PWM 1 OUTPUT CIRCUITRY OR DRIVE ENABLE SWITCH FAILURE] S2 -- NO --> S3[5 DRIVE PWR SW (4) - OFF, THEN BACK TO ORIGINAL POSITION ONE AT A TIME TO ISOLATE ABNORMAL WHEEL] S3 -- YES --> B3[6 DRIVE CONTROL ELECTRONICS FAILURE] S3 -- NO --> S4[7 OPERATE LRV BY RELEASING BRAKE MOMENTARILY TO NEUTRAL TO OBTAIN SPEED AND THEN RETURN IT TO BRAKE IN A CYCLIC MANNER] B3 --> S5[8 AFFECTED WHEEL: - DRIVE PWR SW - OFF - DRIVE ENABLE SW - OFF - DECOUPLE WHEEL] </pre>	<p>1 DO NOT ALLOW DRIVE ENABLE SWITCH TO REMAIN IN OFF POSITION WHILE SWITCHING, OR FULL POWER TO AFFECTED MOTOR WILL RESULT</p> <p>2 IF DECOUPLED WHEEL IS RR, SPEED METER WILL NOT FUNCTION DRIVE AND BRAKING IN ACCORDANCE WITH APPENDIX A</p>
SYMPTOM	PROCEDURE	REMARKS

TABLE 3-2. MALFUNCTION LOGIC FLOW DIAGRAM (CONTINUED)

LS006-002-2h
LUNAR ROVING VEHICLE
OPERATIONS HANDBOOK

SYMPTOM	PROCEDURE	REMARKS
<p>7</p> <p>LOSS OF DRIVE FROM ONE OR TWO WHEELS (COMMANDED ACCELERATION ABNORMALLY LOW)</p>	<pre> graph TD S7[7 LOSS OF DRIVE FROM ONE OR TWO WHEELS (COMMANDED ACCELERATION ABNORMALLY LOW)] --> B1[AFFECTED WHEELS: DRIVE ENABLE SW - ALTERNATE POSITION] B1 --> D1{WHEEL DRIVE OPERABLE?} D1 -- YES --> B2[PWM CIRCUITRY OR DRIVE ENABLE SWITCH FAILURE] D1 -- NO --> B3[AFFECTED WHEEL(S) DRIVE POWER SW - ALTERNATE POSITION] B3 --> D2{WHEEL DRIVE OPERABLE?} D2 -- YES --> B4[DRIVE PWR CIRCUITRY FAILURE] D2 -- NO --> B5[DRIVE SYSTEM FOR AFFECTED WHEEL INOP] B5 --> B6[AFFECTED WHEEL: DRIVE POWER OFF, DRIVE ENABLE OFF, DECOUPLE WHEEL] </pre>	<p>① DO NOT ALLOW DRIVE ENABLE SWITCH TO REMAIN IN OFF POSITION WHILE SWITCHING OR FULL POWER TO AFFECTED MOTOR WILL RESULT</p> <p>② IF DECOUPLED WHEEL IS RR, SPEED INDICATOR WILL NOT FUNCTION DRIVE AND BRAKING IN ACCORDANCE WITH APPENDIX A</p>
SYMPTOM	PROCEDURE	REMARKS

TABLE 3-2. MALFUNCTION LOGIC FLOW DIAGRAM (CONTINUED)

SYMPTOM	PROCEDURE	REMARKS
<p>8 COMMANDED VEHICLE SPEED ABNORMALLY HIGH (SPEED NOT VARIABLE ON ONE OR MORE WHEELS)</p>	<pre> graph TD Start[8 COMMANDED VEHICLE SPEED ABNORMALLY HIGH (SPEED NOT VARIABLE ON ONE OR MORE WHEELS)] --> Step1[1 STOP LRV. DRIVE ENABL SW (4) - PWM 1] Step1 --> Q1{TRACTION DRIVE NORMAL?} Q1 -- YES --> Box2[2 PWM 2 CIRCUITRY OR DRIVE ENABLE SWITCH FAILURE] Q1 -- NO --> Step3[3 DRIVE ENABLE SW (4) - PWM 2] Step3 --> Q2{TRACTION DRIVE NORMAL?} Q2 -- YES --> Box4[4 PWM 1 CIRCUITRY OR DRIVE ENABLE SWITCH FAILURE] Q2 -- NO --> Step5[5 DRIVE PWR SW (4) - OFF, THEN BACK TO ORIGINAL POSITION ONE AT A TIME TO ISOLATE ABNORMAL WHEEL] Step5 --> Q3{ONLY ONE WHEEL AFFECTED?} Q3 -- YES --> Box6[6 DRIVE CONTROL ELECTRONICS FAILURE] Q3 -- NO --> Step7[7 OPERATE LRV BY ACTUATING THE HAND CONTROLLER THROTTLE MOMENTARILY TO FORWARD TO OBTAIN SPEED AND THEN RETURN IT TO NEUTRAL OR BRAKE IN A CYCLIC MANNER] Box6 --> Step8[8 AFFECTED WHEEL: - DRIVE PWR SW - OFF - DRIVE ENABLE SW - OFF - DECOUPLE WHEEL] Step8 --> Note2[2 IF DECOUPLED WHEEL IS RR, SPEED METER WILL NOT FUNCTION] </pre>	<p>1 DO NOT ALLOW DRIVE ENABLE SWITCH TO REMAIN IN OFF POSITION WHILE SWITCHING, OR FULL POWER TO AFFECTED MOTOR WILL RESULT</p> <p>CAUTION SHOULD BE TAKEN SINCE VEHICLE MAY TEND TO ACCELERATE TO MAX SPEED IF SELECTED PWM IS DEFECTIVE</p> <p>2 IF DECOUPLED WHEEL IS RR, SPEED METER WILL NOT FUNCTION</p> <p>DRIVE AND BRAKING IN ACCORDANCE WITH APPENDIX A</p>
SYMPTOM	PROCEDURE	REMARKS

TABLE 3-2. MALFUNCTION LOGIC FLOW DIAGRAM (CONTINUED)

LS006-002-2H
LUNAR ROVING VEHICLE
OPERATIONS HANDBOOK




TABLE 3-2. MALFUNCTION LOGIC FLOW DIAGRAM (CONTINUED)

LS006-002-2H
LUNAR ROVING VEHICLE
OPERATIONS HANDBOOK

SYMPTOM	PROCEDURE	REMARKS
<p>10</p> <div data-bbox="232 265 412 399" style="border: 1px solid black; padding: 5px; width: fit-content;"> BRAKE WILL NOT RELEASE </div>	<div data-bbox="868 265 1047 399" style="border: 1px solid black; padding: 5px; width: fit-content;"> ¹ BINDING, JAMMING OR OTHER MECHANISM FAILURE </div> <div data-bbox="868 472 1055 607" style="border: 1px solid black; padding: 5px; width: fit-content; margin-top: 20px;"> ² AFFECTED WHEEL: - DRIVE PWR OFF - DRIVE ENABLE OFF - DECOUPLE WHEEL </div>	<div data-bbox="1102 430 1293 621" style="border: 1px solid black; padding: 5px; width: fit-content;"> ¹ DRIVE AND BRAKING IN ACCORDANCE WITH APPENDIX A IF AFFECTED WHEEL IS RR, SPEED METER WILL NOT FUNCTION </div>
SYMPTOM	PROCEDURE	REMARKS

TABLE 3-2. MALFUNCTION LOGIC FLOW DIAGRAM (CONTINUED)

LS006-00?-2H
LUNAR ROVING VEHICLE
OPERATIONS HANDBOOK




TABLE 3-2. MALFUNCTION LOGIC FLOW DIAGRAM (CONTINUED)

LS006-012-21
LUNAR ROVING VEHICLE
OPERATIONS HANDBOOK

SYMPTOM	PROCEDURE	REMARKS
11 (CONTINUED)	<pre> graph TD 18[18] --> 20{20 DID CB REMAIN CLOSED?} 20 -- YES --> 26{26 LRV AUX CD - CLOSE POWER SW - EXT COMM OK?} 20 -- NO --> 21{21 SELECT ALTERNATE MODE - MODE PM1/ WE OR FM/TV LCRU CD - CLOSE DID CB REMAIN CLOSED?} 26 -- YES --> 28{28 LOSS OF 28 VOLT BATTERY POWER} 26 -- NO --> 27{27 PROBABLE LRV 28 VOLT WIRING OPEN C. CIRCUIT} 21 -- YES --> 23{23 POINT SELECTED ANTENNA COMM OK?} 21 -- NO --> 22{22 SHORT IN 28 VOLT CIRCUIT} 23 -- YES --> 24{24 S-BAND XMTR SHORTED} 23 -- NO --> 25{25 PROBABLE DAMAGE TO XIDE SWITCH} 22 --> 6((6)) 28 --> 29{29 REPLACEMENT BATTERY MAY RESTORE OPERATION} </pre>	
SYMPTOM	PROCEDURE	REMARKS

TABLE 3-2. MALFUNCTION LOGIC FLOW DIAGRAM (CONTINUED)