

CHROMA PARAMETER CHART

Chris Ryan: chris@rhodeschroma.com
 Rhodes Chroma: www.rhodeschroma.com
 Version 1.1a, June 11, 2002

[SET SPLIT]
FUNCTIONS

1 PATCH 0	6 BATTERY CHECK	11 PROGRAM 0 PACKET	16 PERFORMANCE DISABLE	21 ATTACK THRESHOLD	26 MUTE A CHANNELS	31 (SPECIAL RESET)*
2 OUTPUT 0	7 KILL BAD BOARD	12 PROGRAM 1 PACKET	17 PERFORMANCE ENABLE	22 RELEASE THRESHOLD	27 MUTE B CHANNELS	32 (SPECIAL RESET #2)*
3 OUTPUT 1	8 DISPLAY BAD BOARD	13 PROGRAM n PACKET	18 PANEL DISABLE	23 RELEASE SLOW RATE	28 UNMUTE	33 (SPECIAL RESET #3)*
4 OUTPUT 2	9 TAPPER ON/OFF	14 STOP PACKET	19 PANEL ENABLE	24 RELEASE FAST RATE	29 MUTE OSCILLATORS	34 PRESSURE DISABLE
5 OUTPUT 3	10 CASSETTE MODE	15 OUTPUT SUBROUTINE	20 SEND PROGRAM	25 BRANCH SUBROUTINE	30 TEST LEDs	35 PRESSURE ENABLE
						50 RESET MAIN COMPUTER

*See notes on Chroma site

