Bridge House 17a Maybrook Road Sutton Coldfield West Midlands B76 1AL

Tel: 0121 313 3857 Fax: 0121 313 3860

http://www.thelinuxemporium.co.uk Email: kernel@thelinuxemporium.co.uk

README: Configuration of Edimax USB Wireless Stick with Antenna, USB Stick, PCMCIA and PCI cards with Linux.

Note that the cards work out-of-the box for most distributions using kernel 2.6.24 or greater. This includes Ubuntu Intrepid Ibex 8.10, Ubuntu Hardy Heron 8.04, and Fedora Core 9!!

Unless OpenSUSE 11.0 is installed with the device present it's necessary to copy files from the firmware directory into /lib/firmware. The files are rt2561s.bin for the PCI and PCMCIA devices which is in the /firmware/RT61_Firmware_V1.2 directory on the CD, and rt73.bin for usb devices which is in the /firmware/RT71W_Firmware_V1.8 directory.

For details of configuration with earlier Linux distributions see the README.pdf file on the CD.

Do e-mail or call us if you have difficulties using the devices.