TEST PROCEDURE	TP 108B
Title	Page Number
Vapor Pressure of Gasoline and Gasoline-Oxygenate Blends	1 of 28
Originator	Supersedes
Carl Scarbro	TP 108A
Responsible Organization	Computer Program
Testing Programs Branch, Fuel and Chemistry Services	NA
Type of Test Report        Data Forms and Computer Summary Printout	Data Form Number Forms 108-01, 108-02, and 108-03
Report Distribution	Implementation Date
Chem. Lab Files, Testing Programs Branch Chief, and Program Officer	09-30-94

## **Implementation Approval**

Original Test Procedure Authorized by EPCN #90 on 10-15-90

# **Revision Description**

(1) 09-30-94 The purpose of this change is to revise the procedure as described in EPCN #170.

**Note:** Specific brand names in EPA/EOD procedures are for reference only and are not an endorsement of those products.

# Table of Contents

1.	Purpose
2.	Test Article Description
3.	References
4.	Required Equipment 4
5.	Precautions 6
6.	Visual Inspection 6
7.	Test Article Preparation7
8.	Test Procedure 11
9.	Data Input 14
10.	Data Analysis 14
11.	Data Output 14
12.	Acceptance Criteria 15
13.	Quality Control Provisions17

# <u>Attachments</u>

Attachment A	19
Attachment B	20
Attachment C	21
Attachment D	22
Attachment E	23
Attachment F	24
Attachment G	25
Attachment H	26
Attachment I	27
Attachment J	28

#### 1. Purpose

The purpose of this procedure is to determine the vapor pressure of gasoline and gasoline-oxygenate blends using the Herzog digital vapor pressure analyzer.

This procedure deviates from 40 CFR Part 80, Appendix E, Tests for Determining Reid Vapor Pressure (RVP) of Gasoline and Gasoline-Oxygenate Blends [54 FR 11868 (March 22, 1989) and 55 FR 25833 (June 25, 1990)] in the number of significant figures used to report the test results.

#### 2. Test Article Description

A 1-quart (1-liter) sample container that is 70-85 volume percent filled with a gasoline or gasoline oxygenate blend.

#### 3. References

- 3.1 40 CFR Part 80, Appendix E, Tests for Determining Reid Vapor Pressure (RVP) of Gasoline and Gasoline-Oxygenate Blends [54 FR 11868 (March 22, 1989) and 55 FR 25833 (June 25, 1990)]
- 3.2 "1989 Annual Book of American Society for Testing and Materials (ASTM) Standards;" Section 5; Petroleum Products, Lubricants, and Fossil Fuels
  - 3.2.1 D 4057 "Practice for Manual Sampling of Petroleum and Petroleum Products"
  - 3.2.2 E 1 Specification for ASTM Thermometers
  - 3.2.3 D 4953 Vapor Pressure of Gasoline and Gasoline-Oxygenate Blends
- 3.3 "Operating Instructions for Vapor Pressure Reid Method," Herzog operating manual
- 3.4 "Handbook of Chemistry and Physics," Section D 217, 65th Edition
- 3.5 "Reference Data for Hydrocarbons and Petrosulfur Compounds," Bulletin No. 251, Phillips Chemical Company

### 4. Required Equipment

- 4.1 Herzog semi-automatic vapor pressure analyzer. Refer to 40 CFR Part 80, Appendix E, Annex A1; and Method 2-Herzog Semi-Automatic Method, Step 4.2, for specific description of the following equipment:
  - 4.1.1 Fuel chamber
  - 4.1.2 Air chamber
  - 4.1.3 Transfer apparatus
  - 4.1.4 Mercury manometer
  - 4.1.5 Water bath
  - 4.1.6 Cooling bath

### 4.2 Reagents:

- 4.2.1 n-pentane (pure grade and commercial)
- 4.2.2 3,3-dimethylbutene-1 (pure grade)
- 4.2.3 2,2,4-trimethylpentane (iso-octane) (pure grade)
- 4.2.4 2,2-dimethylbutane (neohexane) (pure grade)
- 4.2.5 3-methylpentane (pure grade)

#### 4.3 Documentation:

- 4.3.1 Form 108-01, RVP Analysis Label (Attachment A)
- 4.3.2 Form 108-02, Vapor Pressure Quality Control Chart (Attachment B)
- 4.3.3 Form 108-03, Herzog Calibration Log (Attachment C)
- 4.3.4 Form 3500-5, EPA Fuels Field Inspection (Attachment D)

	4.3.5	EPA Form 3700-2, Analysis of Lead in Gasoline (Attachment E)
	4.3.6	Target Pressures on Stabilized Air Chambers (Attachment F)
	4.3.7	Precision Data Report - Analysis of Laboratory Duplicates (Attachment G)
	4.3.8	Accuracy Data Report- Analysis of Laboratory Standards (Attachment H)
	4.3.9	Vapor Pressure Statistical Summary (Attachment I)
	4.3.10	Vapor Pressure Precision and Accuracy Calculation Formulas (Attachment J)
4.4	Other E	quipment
	4.4.1	Refrigerator
	4.4.2	Ice machine
	4.4.3	Coolers
	4.4.4	Compressed air/vacuum manifold
	4.4.5	Compressed air and lab vacuum
	4.4.6	Environmental Protection Agency (EPA)-approved fume hood
	4.4.7	8-ounce clear PVC coated bottles
	4.4.8	00 rubber stoppers
	4.4.9	Lab Coat
	4.4.10	Safety Glasses
	4.4.11	Wiper Cloths
	4.4.12	Rubber Gloves
	4.4.13	Waste Can with Fuel Chamber Key

#### 5. Precautions

5.1 Gasoline is flammable and toxic. The test assembly with gasoline is under pressure and can spray the analyst when it is disassembled for cleaning. Analysts must perform all phases of the procedure where the sample container is open under an EPA-approved fume hood. Safety glasses and gloves are required.

Samples must be kept in laboratory areas with single-pass air handling and an automatic fire suppression system. Fume hoods must be cleared of sample and waste products at the end of the work day.

- 5.2 Sample in accordance with 40 CFR Part 80, Appendix D.
- 5.3 All vapor pressure tests will be the first type of analysis performed on a sample. Multiple vapor pressure analyses may be performed on any sample. The order of testing must be recorded.
- 5.4 The transfer apparatus, fuel chamber, and sample must be chilled to 32-34 °F before starting the test procedure. In all cases, cool the sample container and contents to 32-34 °F before opening the container.

To ensure that there is sufficient time to reach this temperature, directly measure the temperature of a similar liquid, in a similar container at a similar temperature, and place it in the ice bath at the same time as the sample.

5.5 Once the test procedure begins, the analyst should proceed with the objective of minimizing the warming of the sample and the chilled hardware before the liquid and vapor chambers are assembled.

#### 6. Visual Inspection

- 6.1 Samples in leaking containers should have Comment Code 1 marked on Form 108-01 (Attachment A). Discoloration of any seals placed over the cap or the presence of gasoline vapors in the shipping container indicates a leak.
- 6.2 Samples in glass containers must be observed for phase separation and clarity after they are cooled to 32-34 °F and before analysis. Samples in metal cans must be observed for those properties after analysis (see Step 109).

For samples in glass containers, shake the container for 5 seconds. Observe the sample for clarity and phase separation.

If the sample is cloudy, mark Comment Code 2 on Form 108-01. If the sample separates into two or more phases, mark Comment Code 3 on Form 108-01.

- 6.3 The Herzog water bath must be filled between the level marks on the Herzog thermometer well.
- 6.4 The ice bath should be a slurry of crushed ice and water. The bath's depth should be such that the surface of the slurry is at or above the surface of the sample in the container.

#### 7. Test Article Preparation

7.1 All samples found to be in violation of the applicable enforcement standard must be analyzed as laboratory duplicates.

Additional samples may be picked at random to be analyzed as laboratory duplicates so that at least 1 sample in 20 is duplicated.

The determination of the transducers to be used, the calculation procedure, and the tolerance to be applied are in Attachment B, Vapor Pressure Quality Control Chart.

The initial analysis will be subtracted from the duplicate. The result is recorded on the control chart and compared with the 95% confidence limits.

Corrective action for an out-of-limits lab duplicate analysis is outlined in Step 12.6.

7.2 A quality control standard is to be analyzed daily as outlined in Attachment B and defined in Step 12.6. The listed Average Pressure for the prescribed control standard will be subtracted from the observed value and the result recorded on Attachment B, Vapor Pressure Quality Control Chart.

Corrective action for an out-of-limits measurement is described in Step 12.7.

7.3 Transducers are calibrated against a mercury manometer at the beginning of each test day and when they differ from 0.00 psi at ambient pressure by  $\pm 0.03$  psi.

The transducer is adjusted to read 0.00 psi at atmospheric pressure and the same pressure as the manometer at an applied pressure of 10 psi-15 psi.

Calibrated transducers will have no correction factor applied to subsequent analyses. The daily transducer calibration is recorded on the Herzog Calibration Log (Attachment C). 7.4 The water bath of the Herzog instrument must be at 100 °F ±0.2 °F. The measuring device must be an ASTM Reid Vapor Pressure Thermometer 18 °F having a range from 94-108 °F and conforming to the requirements in Specification E1.

The thermometer will be located in the Herzog thermometer well.

- 7.5 Document Preparation:
  - 7.5.1 Affix a blank copy of Form 108-01 (Attachment A) to EPA Form 3500-5 (Attachment D) upon removing the sample bottles and Form 3500-5 from the shipper.

Compare the following data on Form 3500-5 with the data on the sample bottle seal, EPA Form 7500-2 (Attachment E).

Sample #

Sample Date

Inspector

7.5.2 If a conflict exists between any of the above data found on Form 3500-5 and the sample seal, Form 7500-2, notify the supervisor immediately and he/she will instruct you which form will be edited (in general, the data on the bottle seal takes precedence).

The analyst will edit the conflicting data by striking a single horizontal black ink line through the incorrect data and clearly printing the correct information, his/her initials, and the date as close to the incorrect data as possible (see Attachment D).

- 7.6 Prior to the initial test, filling of the sample container is verified as follows:
  - 7.6.1 With the sample at a temperature of 32-34 °F, take the container from the ice bath, wipe it dry with an absorbent material, and measure its ullage. The sample content, as determined by a gauge designed for the specific container, shall equal 70%-85% of the container capacity.
  - 7.6.2 If the sample container is less than 70% full, mark Comment Code 4 on Form 108-01. If it is greater than 85% full, mark Comment Code 5 on Form 108-01.

TP 108B		Vapor Pressure of Gasoline and Gasoline-Oxygenate Blends	Page 9 of 28
	7.6.3	If the container is more than 80% full, pour out enough sa container contents within the 70%-80% range. Under no any sample poured out be returned to the container.	
		If the sample is less than 70% full after the above operation Code 6 on Form 108-01.	n, mark Comment
	Note:	The sample must be 70-85% of container capacity when remust be within 70-80% to complete this test.	ecieved and it
7.7	Air satu	ration of the sample in the container is as follows:	
	7.7.1	With the sample at a temperature of 32-34 °F, take the corrice bath; wipe it dry with an absorbent material; unseal it f seconds, taking care that no water enters the sample; re-se vigorously for 5 seconds.	for several
		Return it to the bath for a minimum of 2 minutes.	
	7.7.2	Repeat Step 7.7.1 twice for a total of three air saturations. sample to the ice bath for at least two minutes before begin	
7.8	Cleanin is as fol	g of the air chamber, fuel chamber, T-handled coupler, and llows:	transfer apparatus
	7.8.1	Disconnect the quick action T-handled coupler. Separate gasoline chambers and discard any remaining sample.	the air and
		Rinse the chambers and the transfer connections in a man the inner surfaces are wetted with commercial grade n-per rinse into the waste can with the fuel chamber key.	
		Dry the interior surfaces of the chambers with dried and fi air or by connecting them to a vacuum source. Dry the T- and spiral tubing by connecting them to a vacuum source dried and filtered compressed air through them.	handled fitting
		Use the gasoline chamber as the air chamber stoppering de water from entering the chamber during its equilibration to for the next test.	
	7.8.2	Rinse the interior surfaces of the transfer apparatus with con- n-pentane. Dry the interior by blowing dried and filtered of by connecting to a vacuum source.	

TP 108B		Vapor Pressure of Gasoline and Gasoline-Oxygenate Blends	Page 10 of 28
7.9	Prepara	tion of the air chamber is as follows:	
	7.9.1	Inspect the teflon washers at both ends of the air chamber. free of dirt or other particles. If they are not, clean them w	
		If they can not be cleaned, replace them with new ones.	
	7.9.2	Screw the T-handled fitting into the smaller opening in the Seal the larger opening with a clean and dry fuel chamber.	
	7.9.3	Check the transducer display for transducer drift. It must psi.	read 0.00 ±0.03
		If it does not, calibrate the transducer as described in Step	7.3.
	7.9.4	Connect the assembled chambers to the transducer with th fitting on the T-handled fitting. Observe the air temperatu chambers were stored before assembly.	
		Immerse the assembly to its test position in the 100 °F $\pm 0$ . for not less than 10 minutes just prior to coupling it with a chamber.	2 °F water bath sample-filled fuel
		The indicated pressure should stabilize according to the ab temperature and to the values stated in Attachment F with	
		If the pressure is below the lower value, check for leaks in T-handled fitting.	the chamber or
		If the pressure is high, the chambers may be contaminated cleaned again.	and must be
		If the pressure is within specification, do not remove the c water bath until the fuel chamber has been filled with same Step 101.	
7.10	passed	bare the fuel chamber, seal, the inlet of a fuel chamber that has the pressure check in Step 7.9.4 with a 00 stopper and place bath for at least 10 minutes.	
	Keep th threads.	e fuel chamber upright and do not immerse it over the top of	f the coupling

7.11 The transfer apparatus is cooled to 32-34 °F by placing it in a cool air bath at 32-34 °F for at least 10 minutes.

#### 8. Test Procedure

- 101 To transfer the sample, remove the chilled sample container from the ice bath, dry the exterior of the container with an absorbent material, uncap the container, and insert the chilled transfer apparatus.
- 102 Remove the fuel chamber from the ice bath, dry it with an absorbent material, and invert it over the shorter tube of the transfer apparatus.
- 103 Invert the entire system rapidly so that the fuel chamber is upright, its bottom is engaged with the chamber key in the gasoline waste can, and the end of the transfer apparatus touches the bottom of the fuel chamber.
- 104 Fill the fuel chamber so the sample overflows the chamber and drains into the waste can. Withdraw the transfer apparatus from the chamber, while allowing the sample to continue flowing up to the moment of complete withdrawal.
- 105 To assemble the apparatus, disconnect an air chamber meeting the conditions of Step 7.9.4 from its transducer. Remove the air chamber from the water bath and quickly dry the exterior of the chamber with an absorbent material, giving particular attention to the connection between the air chamber and the fuel chamber.

Remove the chamber that was used to seal the air chamber (this fuel chamber may now be placed in the ice bath to be used in subsequent tests).

As quickly as possible, without spilling the sample, couple the air chamber to the filled fuel chamber. The assembly must be done without undue movement, which could promote exchange of room temperature air with the 100 °F air in the air chamber.

Not more than 10 seconds shall be consumed in coupling the two chambers.

106 To introduce the apparatus into the bath, hold the apparatus vertically, air chamber end up, and immediately reconnect the spiral tubing to the transducer with the quick disconnect fitting.

Rotate the apparatus 110-120 °F, air chamber end down, for 5 seconds to allow sample to flow into the air chamber without getting into the spiral tube.

Increase the angle of the tilt vertically with the air chamber end down and hold until the pressure increases slowly (approximately 0.01 psi per second). This takes about 20 seconds.

Place the assembled apparatus into the 100 °F  $\pm 0.2$  °F water bath so that the bottom of the fuel chamber engages the drive coupling and the other end rests on the support bearing.

- 107 Record on Form 108-01 the transducer number, the time of day, the analysis date, and the analyst's initials. Return the re-sealed sample to the ice bath.
- 108 Observe the apparatus for leaks throughout the test. Vapor and liquid leaks under the surface of the water bath will be continuous and visually evident.

Leaks in the air chamber to the transducer connector can be detected through any decrease of measured vapor pressure. In case of any leaks, record the highest vapor pressure reading as the sample's Reid Vapor Pressure and mark Comment Code 7 on Form 108-01.

Tag all associated chambers, fittings, and transducers as suspect, and immediately notify the supervisor of possible equipment problems.

109 If the sample is in a metal can and no further analyses are to be performed on the sample, check the remaining sample for phase separation. This is done by shaking the container for 5 seconds and pouring a quantity of the sample into a clear glass container.

Observe it as in Step 6.2.

If the sample is cloudy, mark Comment Code 2 on Form 108-01. If the sample separates into two or more phases, mark Comment Code 3 on Form 108-01.

110 To measure the vapor pressure, observe and record the transducer reading to the nearest 0.01 psi after the assembled apparatus has been in the bath for at least 5 minutes.

At intervals of not less than 2 minutes, observe and record pressure readings until the last consecutive transducer readings are within 0.01 psi of each other. The last reading is the Reid Vapor Pressure.

On EPA Form 3500-5, record this value to the nearest 0.01 psi as the Reid Vapor Pressure of the sample.

111 To verify the integrity of the sample contained in the assembled apparatus, perform the following operations immediately after removing the assembly from the water bath: Dry the exterior surface with absorbent material and, with the assembly in an upright position, vent the pressure by removing the T-handled fitting and spiral tube.

Caution: not venting in this manner may result in the dangerous spraying of gasoline through the vapor chamber pressure relief vent onto the operator and into the room.

Disconnect the air chamber from the fuel chamber. Drain the contents of the fuel and air chambers into a dry, 8-ounce clear glass bottle. Seal the container and shake it vigorously for 5 seconds.

Determine whether the sample is clear and bright and free of a second phase.

If it is not, immerse the bottle in the 100 °F water bath to about 1 inch above the top of the sample level for at least 15 minutes in order to heat the sample to test temperature.

Remove the sample from the water bath, immediately shake it vigorously for 5 seconds, and observe the sample.

If the sample is not clear and bright and free of a second phase, mark Comment Code 8 on Form 108-01.

112 Compare the RVP standard on EPA Form 3500-5 with the measured pressure of the sample(s) identified on the form.

If the measured vapor pressure exceeds that value, the sample must be analyzed again. Start with a chilled sample (32-34 °F) and proceed to Section 8, Step 101.

A tag must be tied to the sample. That tag will have written on it: the sample number, the Field Operations Support Division (FOSD) office responsible for the area from where the sample was taken, the date it was received, and the date it was analyzed for vapor pressure.

113 Review EPA Form 3500-5 for any further analyses requested by FOSD for the sample(s) in question.

If further analyses are requested, a tag is tied to the sample. The tag will have written on it: the sample number, the FOSD office responsible for the area from where the sample was taken, the date it was received, the date it was analyzed for vapor pressure, and the other analyses requested.

Custody of the sample will be given over to the analyst responsible.

#### 9. Data Input

- 9.1 Form(s) 108-01 must be filled out in full and affixed to EPA Form 3500-5. These documents will be used to generate FOSD and Fuels and Chemistry Service (F&CS) reports on the analyses of the individual samples.
- 9.2 Form 108-03, Herzog Calibration Log, and Form 108-02, Vapor Pressure Quality Control Chart, are stored in log books in the Physical Chemistry Laboratory.

They document F&CS's conformance to this procedure and are used by F&CS to generate its monthly test and periodic quality control reports.

#### 10. Data Analysis

10.1 The analyst must verify the completeness and accuracy of Form 108-01; EPA Form 3500-5; Form 108-03, Herzog Calibration Log; and Form 108-02, Vapor Pressure Quality Control Chart .

All corrections to these forms must be dated and initialed.

10.2 The duplicate and standard data on the above forms will be used to calculate precision and accuracy.

#### 11. Data Output

The completed EPA Forms 3500-5 and Form 108-01 will be photocopied. The originals will be given to FOSD's data staff.

They will enter the data into their data handling system to produce reports for their needs. They will retain the original forms and use them as evidence in case of litigation.

F&CS will use the copies to produce the monthly Results of Gasoline Analyses report and the Precision and Accuracy of Vapor Pressure Testing report (see examples at Attachments G through J).

#### 12. Acceptance Criteria

- **Note:** Steps 12.6 through 12.8 are included specifically to define data quality as required by EPA Order 5360.1, Policy and Program Requirements to Implement the Quality Assurance Program. They should not be interpreted as a change in EPA's policy regarding enforcement tolerance as set forth in 54 Federal Register 11877 (March 22, 1989).
- 12.1 The sample container did not leak.
- 12.2 The sample container was 70%-85% full.
- 12.3 The sample, as received, and the analysis sample did not phase separate and were not cloudy.
- 12.4 The apparatus did not leak.
- 12.5 Duplicate analyses were done at the frequency stated in Step 7.1 and met the following criteria:
  - 12.5.1 The difference between successive test results obtained under constant operating conditions and identical test materials would, in the normal and correct operation of the test method, exceed the following value only in 1 case in 20.

The field duplicate precision data was based on a 1988 ASTM cooperative test program. The laboratory duplicate precision data was based on the 1989 EPA Enforcement Program.

Sample <u>Type</u>	Container <u>Volume</u>	Container <u>Type</u>	95 % Tolerance (psi)
Field Duplicate	1 quart	glass	±0.26
Lab Duplicate	1 quart	glass	+0.20 to -0.22

12.5.2 When the absolute difference between field duplicates exceeds the applicable tolerance, analyze the samples again using the same transducers. However, each sample will be tested with the transducer that was not used for the original test.

If the resulting pair of lab duplicates and the field duplicates are within their respective tolerances, the initial analyses are considered the 1-in-20 out-of-tolerance analyses which are expected for this process. Continue the analyses.

If both sets of field duplicate analyses are out of tolerance and both sets of lab duplicates are within tolerance, a sampling or sample handling error may have occurred.

If possible, new samples should be taken and analyzed.

If either of the lab duplicates are out of tolerance, the process is considered out of tolerance; proceed to Step 12.5.3.

12.5.3 When the absolute difference between laboratory duplicates exceeds the applicable tolerance, the analyst must examine the transducer calibration, check the test assemblies for leaks, and notify the supervisor.

If the equipment is at fault, the process is considered out of tolerance. Proceed to Step 12.7.

If the transducers are calibrated correctly and there are no system leaks, the sample will be analyzed again.

If the second test set is within tolerance, the initial set is considered the 1-in-20 analyses out of tolerance which is expected for this process.

If not, the process is out of tolerance; proceed to Step 12.7. All duplicate data will be recorded and reported for the monthly quality assurance report and on the Vapor Pressure Quality Control Chart.

- 12.6 Analysis of standards must meet the following criteria:
  - 12.6.1 A quality control standard must be analyzed once a day for each instrument in use that day. The QC standard and transducer used are identified in the Vapor Pressure Quality Control Chart (see example, Attachment B).

If the measured vapor pressure of a standard exceeds the stated tolerance, analyze the next standard in the schedule (see example, Attachment B).

If that standard is in conformance with the acceptance criteria, the initial analysis is considered the 1-in-20 out-of-tolerance measurement expected for this process; continue to analyze samples.

If not, the process is out of tolerance; proceed to Step 12.7.

12.6.2 EOD has established a bias statement for the following four pure hydrocarbon compounds. This data was based on analyses done during EPA's 1989 Volatility Enforcement Program except for iso-octane, which was done at EPA prior to that date.

	• •		× <b>1</b> – /		
	Published			95% To	olerance
<u>Compound</u>	<u>VP (psi)</u>	<u>n</u>	<u>Mean</u>	Lower	<u>Upper</u>
iso-octane	$1.7\bar{1}$	9	2.02	1.84	2.20
3-methylpentane	6.10	19	6.23	6.05	6.42
2,2-dimethylbutane	9.86	26	9.89	9.70	10.08
n-pentane	15.57	20	15.38	15.16	15.60

Dry Reid Vapor Pressure (psi)

12.7 The analyst, in conjunction with the supervisor, must attempt to identify the source of the out-of-tolerance situation. Corrective action will be taken to ensure that further analyses meet the specifications of this procedure. They must also identify what analyses may be affected by the out-of-tolerance situation.

The above information must be written on a Discrepant Test Review Form 106-01 and submitted for review, along with a copy of the applicable Vapor Pressure Quality Control Chart (Attachment B), to Quality Control.

Disposition of the sample measurements in question will be determined jointly by Quality Control, the analyst, and the supervisor.

12.8 Values found in the tables in Steps 12.5.1 and 12.6.2 will be updated every November to reflect the changes in precision and accuracy measured from the preceding year.

#### **13.** Quality Control Provisions

- 13.1 Daily transducer calibration.
- 13.2 Visual inspection for leaks, phase separation, and minimum and maximum volume limits of the sample in the sample container.

- 13.3 Pretesting of the vapor and liquid chambers for contamination and leaks.
- 13.4 Samples found to be in violation of the RVP standard on EPA Form 3500-5 are analyzed as laboratory duplicates. At least 1 sample in 20 must be a laboratory duplicate.
- 13.5 Analysis of one standard sample per instrument per day.
- 13.6 Adherence to the Vapor Pressure Quality Control Chart (Attachment B) for the analyses of duplicates and standards.

Attachment A


RVP Analysis Label (Form 108-01) and a definition of Comment Codes

Sampin D Sets Fiel Analyst Communic Code(s) 7 2 ;
T = Transforme 1, 2, or 3; I = Datresant 1 or 2 f
Form 108-01 9/8/90
Gignature: Datas

Comment Codes:

- 1. There is evidence that the sample container leaked.

- The sample upon chilling to 32-34°F is cloudy.
  The sample upon chilling to 32-34°F separates into two or more phases.
  The received sample container upon chilling to 32-34°F is less than 70 % full.
  The received sample container upon chilling to 32-34°F is greater than 85% full.
- 6. The received sample container upon chilling to 32-34°F and subsequent removal of sample in excess of 80% is below 70 %.
- 7. The test apparatus leaked during the analysis of the sample.
- B. The analysis sample is cloudy or has two phases.



**TP 108B** 

]	2														Ţ		Ī	Ţ					T L	
	L					Ī												Ĺ						
											ĺ												L	
Π	aud euez	Morcery Herzeg	ĺ	Ţ	Γ	T																		
Inni	led-aunte	Harzeg	ļ	Γ	ļ											ļ		Ĺ						Ĺ
Transducer #1	jad-öünesese upd§ jad-öün <del>es</del> ese esez	Mercury Herzog		Į																	Ĺ		Ĺ	
	laure-psi	Herzag	ļ	Γ														ļ		ļ			Į	
] .	Zero pri	Moreury		Ī	ſ																			Γ
	Esure-ps	Moreury Herzeg		ſ																				
Transdacer #2	Zero prossura-psi Span pressure	Mercary Herz	Π	ſ																ļ			Γ	
	#q-eruse	Herzog	ļ																					
Ī			Ī							Ī	Ī											Γ	ĺ	
	pd-cunsació olaz	Rüzsen Eintem	Ħ	- 					1			ſ								i		ļ		
Instrument :	i Spen pri	Bezieh Rinautik																						
	- 616684	Herze	ťſ	-	-			╏			ļ	┫	┫		-	-					F			

**TP 108B** 

Aitachmént C

#### Attachment D

_	-BPX	-					Fuels Fi	ad inspe	ction	1		сv4.			1005
_	24-	ə mətə Sənərə					14:13	2 Banks	- 60			╺╼╸	HER Case		*
+	ani ani ya							]Ømani Barter			Caurier	<u> </u>			
		_	The second	- <b>1</b>			NE SHALT STRE			ni Liji Treading Instrum	e i	-		Constituted	
. 1	α y	in one	tien -	_											
	, Nama ,	Y P	4 -	May			Lise:	Crash ( Second					aris Telepho	a la parte	-
-			•				<u> </u>	C Y	<b>.</b> .	_			14 A F	9 92	90
~	۲.		ų B		<u> </u>	city Owner		Ann	<u> 6- 6</u>	ia et Listing Plans	<u>.                                    </u>	l m	vr -	(\$103	<u> </u>
监		<u>1</u> 1	ine.			Luly	<u> </u>	Elever .							
		- here -	- <b>-</b>	-			Sune -	B	٨	Scarb	-11		At.	-	÷=+
	Tere	Pop		ina inter Persod		80'80.4	Rui Barra		inite radio			4. T	ad Reivi	-	
-	-	*8	<b>0</b> H	Octore		uten Pre	Prese	Per Beggtone	-		<u> </u>	1	Teres Types	Ter	Task She.
-	i		-+	<u>.94</u>		<u>.41:6</u>		4/90	5190	MI.	_	1	12	1	10.7
2	<u>2</u> و		╼ <u>─</u> ┤	ši-	_	1.12.0		¥/%	5/10	mI		2	12	2	10.3
4	~	_/8	•	93.		1.56	+	4/20	-12-	MI		3	11	_1	10.8
+			╸┼				<u> </u>				<b></b>	3	11		8, (
+			•				╎──┊					1	60		18.8
	ena pire	Inform	a. 1 Maran	d Find V	i Acieniane	<u> </u>	· _ ·	I	_		4	5	60	<u> </u>	10.5
	Chante	<b>Test</b>	Pump	Bashyla- See	Type	- Fush Volume		, Territ or Valtitute 2.1		1.5	- 10 m	<u> </u>	60	<b>⊢</b>	11.3
	1	j	31	7		/2.2		TANDARS	-			Ŧ	60	-	10.7
!	2	2	213	1.7		9.6		CHAIN OF CHILDS		-	-+	2		-	10.6
ľ	3	3	404	14		1.3	سر همر				-+	6 6	60 50		$\frac{11.2}{2}$
•	1	i	31	9	<b>F</b>	12.2			290	· · ·	-	•	30	╞╺┺──	7.1
i T	2	2	3.3	7	-	9.6	Seuts Com #	<u>6.4</u>	م <u>م الم الم الم الم الم الم الم الم الم ال</u>	· ·					[
1	3	٤	967	7		43									<u> </u>
<u> </u>				<u> </u>		· · ·	Says ==		1614	<u>4.5.6</u>					
<u>۱</u>						<u> </u>	Dits method	• • • • • • • • • • • • • • • • • • •	10110		2	N 11 DE	d Nozan	32,019	
				I						-		61212	oothly Type	Tan 🕑	
1	) Joanne		_						- Igoda	-					
		( 5 7.	4/-/7/ 4/-/1 4/-/1 Transd	2 112 2 124 2 124 2 124 2 124	* * 8. or	ynt Columnt ( 				Pale Tan Risto IS Risto IS Ris	25 27	r 3; _For	L > Insi nu 106-01		<u>→</u> <u>→</u> <u>→</u> <u>→</u>
			- <sub>[</sub> a	JJT	27-64.7		11491			EOCA	opea e	-	•	1/.6	170
		Cara	<u></u>				der's filment (schut)				B				

			ATTAC	hment e			
		E	NGINBERING OF Analysis Of L			Re	port No
			th:	rough			
ample ID	Gustemer	Source of Sample	Results From <u>Earlier Tost</u>	Received	Analysis		
• • • • • • • • • • • • • • • • • • •			<u> </u>				
-							
							• • •
certify	that t e with A	hese analys STM D 3237.	es were perfo	ormed using	; Atomic /	<u> </u>	pectroscopy in
certify	e with A	STM D 3237.				Absorption S	pectroscopy in
iccordanci Is our ur 100 gm/g based on d	e with A Signa nit is c al and . calculat	STM D 3237. ture: urrently ca 003 gm/gal, ions after c		upper and Results diluted sau	Date: lower li which are mple.	Absorption S mits of det above the u	pectroscopy in - ectibility are pper limit are
iccordanci Is our un 100 gm/g based on o Sample	e with A Signa nit is c al and . calculat	STM D 3237. sture: urrently ca 003 gm/gal, ions after 6 e discerded Lead test	librated, the respectively. analysis of a after 3 month t kit (ASDM	upper and Results diluted sau s unless co D 3348).	Date: lower li which are mple. ustomer re The up	Absorption S mits of det above the u equests other per and low	pectroscopy in 
iccordanci Is our ur 100 gm/g based on d	e with A Signa nit is c al and . calculat s will b	STM D 3237. sture: arrently ca 003 gm/gal, ions after c e discerded Lead test detectibil	librated, the respectively. analysis of a after 3 month t kit (ASIM lity are .05 g sorption Spect b test us tests	upper and Results diluted sau s unless c D 3348). m/cal and	Date: lower li which are mple. ustomer re The up .01 gm/gal	Absorption S mits of det above the u quests other over and low	pectroscopy in 

#### Attachment F

Pre-essembly Chamber	Pressure	
Temperature * F	Ninimum	Max <u>imum</u>
62	0.94	1.14
63	Q.91	1.11
64	0.68	1.08
66	0.85	1.05
66	0.82	1.02
67	0.78	0.99
48	0.77	0.97
69	0.74	0.84
70	0.71	0.81
71	0.68	0.88
72	0.65	0.85
73	0.62	0.82
74	0.69	0.79
75	0.57	0.77
76	0.54	0.74
77	0.51	0.71
78	0.48	0.68
79	0.46	0.66
80	0.43	0.63
81	0.40	0.60
82	0.37	0.57
83	0.35	0.55
84	0.32	0.52
85	0.29	0.49
86	0.27	0.47
87	0.24	0.44
66	0.21	0.41
69	0.19	0.39
90	0.16	0.36
91	0.13	0.33
92	0.11	0.31
93	0.08	0.28
94	0.05	0.25
95	<u> </u>	0.23

Target Pressure Rise of Clean and Dity Chambers After Heating to 100°F

Table based on the ideal gas law and trial tests at a barometer reading of 29.07 in Hg

Page 1 39/27/50

# Analysis of Laboratory Duplicates

Precision Data for the Analysia of RVP of Gasoline

	<b>B</b>	Vepo	r Pressure - pel	I	
Sample Id	Date of Analysis	initial	Duplicete	Difference	Within the 66% Confidence Interval
1009637-1 Sample was cloudy	08/27/90	8.66	0.62	-0.16	Yes
1011005-1	02/07/90	9.71	9.85	0.14	Yes
1011007-1	02/13/50	1.31	8.21	0.00	Yes
1011018-1	06/13/50	9.51	9.63	0.02	Yes
1011037-1	06/13/90	8.65	6.80	-0.03	Yee
1011049-1	08/13/90	8.30	8.36	0.06	Yes
1011058-1	05/14/50	959	9.63	0.05	Yes
1011081-1 Sample was cloudy	06/14/90	8.37	8.42	0.05	Yes
1011054-3	05/14/90	10.31	10.29	-0.02	Yes
1011079-1 Sample was cloudy	06/21/90	4.60	8.70	0.10	Yes
1011082-1	05/21/90	8.65	4.73	0.05	Yes
(011083-1 Sample was cloudy	05/21/90	8.58	8.82	-0.08	Yes
1011093-1 Semple was cloudy	08/21/90	6.74	4.47	-0.07	Yes
1011101-4	08/22/90	10,41	10.41	0.00	Yee
1011102-2	02/22/90	10.42	10.42	0.00	Yes
1011105-4	08/22/90	11.14	11.20	0.06	Yes
1011105-5	08/22/90	10.97	10.91	-0.08	Yee
1011105-6	08/22/90	10.73	10.69	-0.14	Yes
1011109-6	06/22/90	10.99	10.97	-0.02	Yes
1011134-1	08/08/90	10.45	10,45	0.00	Yes
1011134-2	05/05/90	10.27	10.24	-0.03	Yes
1011255-6	08/01/90	10.40	10.27	-0.13	Yes
1011266-2 Sample was doudy	08/15/90	10.75	10.79	0.04	Yes
1011265-3 Sample was cloudy	0\$/15/90	10.69	10.75	0.07	Yes
1011259-11 Sample was cloudy	08/15/90	10.58	10.69	0.06	Уве
101 <b>1260-12</b> Sample was cloudy	08/15/90	10.80	10.64	0.04	Yes
1011289-1 Sample was cloudy	08/15/80	10.58	10.48	0.04	Yes
1011289-3 Sample was cloudy	06/15/90	10.89	10.45	0.05	Yes

95 % Confidence Interva: -0.22 <= (Duplicate-Initial) <= 0.20 Comments (when applicable) follow the sample Attachment Q

Page 1 09/27/90

# Analysis of Laboratory Standards

Date for the Analysis of RVP Standards

		Vapo	r Provente - pi	al .	Within the 98%
Sample M	Date of Analysia	Average	Measured	Difference	Confidence Interval
2,2-denethylbutane	01/02/90	9.69	9.95	0.08	Yea
2,2-dimethyliputane	08/02/90	9.89	9.79	-0.13	Yee
2,2-dimethylbutane	05/05/90	9.69	9.87	-0.02	Yes
2,2-dimethylic tane	08/08/90	9.69	9.98	0.09	Yea
2.2-dimethyBullane	CE/14/90	9.89	9.86	-0.03	Yee
2,2-dimethylbulane	08/14/90	9.89	9.65	-0.03	Yee
2,2-dimethylbutune	06/16/90	9.80	9.90	0.01	Yee
2,2-dimethylikutané	06/20/90	8.88	9.94	0.05	Yes
2,2-cimolhyibutane	08/20/90	9.89	10.03	0.14	Yes
2,2-dimethylibutane	C8/24/90	9.69	9.65	0.09	Yet
2,2-dimethylix#ane	05/24/60	9.89	9.66	-0.03	Yes
2,2-dimethylicul une	08/30/90	9.69	9.95	0.08	Yes
3-methylpentane	08/01/90	6.23	6.39	0.18	Yes
3-methylpentane	05/01/90	6.23	8.38	0.13	Yes
3-methylpentane	08/07/90	6.23	0.41	0.18	Yee
3-methylpeniane	08/07/90	6.23	6.25	0.02	Yes
3-methylpeniane	06/13/50	6.23	6.05	-0.16	Yes
3-methylpenture	08/13/90	6.23	8.14	-0.09	Yes
3-methylpentere	08/23/90	5.23	6.37	0.14	Yee
3-methylpentene	02/23/90	6.23	6.33	0.10	Yee
3-mathylpentane	05/25/90	6.23	6.25	0.02	Yes
3-methylganiane	05/29/90	6.23	6.27	0.04	Yes
3-methylpeniane	08/29/90	6.23	5.22	-0.01	Yee
3-methylpentane	08/25/90	8.29	6.27	0.04	Yes
3-methylpenture	06/29/90	8.23	6.22	-0.01	Yes
ao-catláne	08/05/00	2.02	1.99	-0.03	Yea
iso-octane	04/10/90	2.02	1.99	-0.03	Yee
iso-actime	08/10/90	2.02	1.95	-0.07	Yes
iso-octane	00/15/20	2.02	2.10	0.68	Yes
isc-octane	06/16/90	2.02	1.99	-0.03	Yes
leo-actions	05/22/90	2.02	2.02	0.00	Yes
iso-octane	65/22/90	2.02	1.94	-0.04	Yes
iap-octane	06/26/90	2,02	2.04	0.02	Yes
·····					

#### 66 % Confidence Interval of Veper Pressure Blandersis in pai

Glandard	Lower	Upper
iso-octans	1.84	2.20
3-methypentar#	6.05	6.42
2,2-classify/butan	6 8.70	10.00
1-contributan	15.18	15.00
n-peritine	10.10	13.09

Attachment H

#### Attachment I Statistical Summary Vapor Pressure of Gasoline EOD 1989 May June ASTM D 4953 1990 Guidelines pre-enforcement Enforcement 1990 Precision Recealability Field Duplicates 10 696 6 270 ±0.14 ±0.11 ±0.26 ±0.24 95 % Confidence Interval Lab Duplicates (a) (a) · 49 267 43 118 П -0,04 -0.01 0.00 0.00 Bina 0.17 0.20 0.19 0.15 Upper 95 % Confidence Interval (4) -0,18 -0.17 ίΞ. -0.23 -0.22 Lower 95 % Confidence Interval Reproducibility 11 (ii) (iii) 15 270 37 ±0.31 ±0.84 ±0.76 95 % Confidence Intervill ±1.00 Accuracy iso-ootane 11 9 (a) 4 (0) fi. 2.02 (m) (m) 1.98 2.01 Average Measured Pressure (e) 2.14 Ì 2.23 2.20 Upper 25 % Confidence Interval 1.41 1.75 1.64 (9) Lower 95 % Confidence Interval 3-methyloentene 19 5 7 (4) . п Average Measured Pressure Upper 95 % Confidence Interval Lower 95 % Confidence Interval 5.29 6.19 6.29 1.23 6.35 6.42 6.05 6.46 6.55 6.02 6.04 6.13 2,2-dimethyloutane 11 45 26 9 (0)n 9.89 Average Measured Pressure Upper 95 % Confidence Interval 9.92 9.89 9.95 (4) 10.08 10.12 10.09 10.14 9,68 9.77 9.69 9.70 Lower 95 % Confidence Intervel 3,3-dimethybutene-1 19 (8) (n) 11 n (1) 13.01 (m) (m) Average Measured Pressure Upper 95 % Confidence Interval (...) Ì 13.07 13.31 13.17 Lower 95 % Confidence Interval 12.62 12.64 (0) (0) n-pertane 20 8 (4) 37 п 15.38 Average Measured Pressure Upper 95 % Confidence Interval Lower 95 % Confidence Interval 15.43 15.34 15.38 15.54 15.22 15.60 15.51 15.61 15.26 15.16 15.26 0.239 (0) (a) (1) (A) Method Dection Limit

(a) not addressed

Precision and Accuracy Calcu Vapor Pressure of G	
Statistic	Formula
Repeatability field duplicates	
difference	d=ebsolute(duplicate-initial)
Standard Deviation	$s_z = (\sum d^2/2n)^{1/2}$
confidence limits cround an individual analysis	=±(1a,0.975)*( \$x)
confidence limits around the difference	
between two analyses of the same materials within the same laboratory	=±(2 <sup>1/2</sup> )" (t <sub>n,0.975</sub> )"( * <sub>2</sub> )
-	
Repeatshilly lab duplicates dilference	d=(duplicate-initial)
average blas	dx-Ed/n
Slandard Deviation	$s_{d} = ((\Sigma d^2 - (\Sigma d)^2 / n) / (n-1))^{1/2}$
confidence limits around the average bias for the	
difference between the original-sample and the	
second-sample values from the same container	=d <sub>x</sub> ±(t <sub>n-1,0.975</sub> )*(*2)
Reproducibility	
difference	d=abaolute(duplicate-initiet)
Standard Deviation	e <sub>2</sub> -(Σd <sup>2</sup> /2n) <sup>1/2</sup>
confidence eround en individual	
observation	=±(t <sub>n,0.075</sub> )*( * <sub>x</sub> )
contidence interval for the difference between	
a single test result obtained in one laboratory	
and a single test result obtained in another laborate	=±(2 <sup>1/2</sup> )* (t <sub>0.0.975</sub> )*( = <sub>x</sub> )
on the same material	=1(2 <sup>()</sup> = ) ((n,0.975) ( =x)
Accuracy	d=(observed-average)
difference evenge blas	dx=∑d/n
Standard Deviation	sd=((Zd <sup>2</sup> -(Id) <sup>2</sup> /n)/(n-1)) <sup>1/2</sup>
confidence interval around the average blas	-0-//we /ert
for an individual analysis	=dx±(tn-1.0.978)*(%)
Method Detection Limit Standard Deviation, e <sub>x</sub> , where x is a standard	
al a concentration very close to or al the	
method detection limb	$=_{x}=((\Sigma x^{2} \cdot (\Sigma x)^{2}/n)/(n-1))^{1/2}$
Method Detection Limit (one-sided 99% confidence	-X-//24 (B-/ (B//))////////
Mainog Unincean Umit (ami-sage earle contoeria) limit an an Individual observation)	= (1 <sub>0-1.0</sub> .99)*( a <sub>z</sub> )
	- vn-1,0.997 v *zr