

Characterization and Metrology for ULSI Technology 2000 International Conference

Spectroscopic Ellipsometry from the Vacuum Ultraviolet to the Far Infrared

John A. Woollam, James N. Hilfiker, Blaine Johs, Craig M. Herzinger, Corey L. Bungay, Ron Synowicki, and Tom Tiwald

J.A. Woollam Co., Inc., 645 M Street, Lincoln, NE 68508

## **Presentation Outline**

- Ellipsometry basics. Thin-films.
- Modern Instruments: VUV to far-IR.
- > *Ex situ* examples.
- In situ examples.
- What's new?
  - Generalized ellipsometry: anisotropy
  - Depolarization: backside/roughness; Patterned wafers
  - Integrated metrology



### **Ellipsometry Overview**



Ellipsometry measures the change in polarization state of light reflected from a sample surface.

$$\mathbf{r} = \tan(\Psi)e^{i\Delta} = \tan\left(\frac{R_p}{R_s}\right)e^{i\left(\mathbf{d}_p - \mathbf{d}_s\right)} = \frac{E_p^r/E_p^i}{E_s^r/E_s^i} = \frac{R_p}{R_s}$$



### **Interaction of Light with Thin Film**

> Optical constants N = n + ik, or  $\varepsilon = \varepsilon_1 + i\varepsilon_2 = N^2$ determine reflected/transmitted intensities, phase change, and angle change.





### **SE Data Analysis FlowChart**



## **Ellipsometry Advantages**

- Measures ratio of two values
  - Highly accurate & reproducible (even at low light levels)
  - No reference necessary
  - Not as susceptible to scatter, lamp or purge variation
- > Measures a 'phase', ' $\Delta$ '
  - Very sensitive, especially to ultrathin films (<10 nm)
  - Provides TWO values at each wavelength
- Spectroscopic Ellipsometry (SE)
  - More Information More Film Properties
  - Data at wavelength of interest (157nm,193nm,248nm...)





- Spectral Range:
  - 193nm to 1700nm
- Automated Angle
- Variable Angle Spectroscopic Ellipsometry, Transmission and Reflection.







### **IR-VASE® Hardware**





## **VUV-VASE<sup>TM</sup> Instrumentation**

- Auto Angle: 10°-90°
- Wavelength 146nm-1100nm
- > Nitrogen Purge
- AutoRetarder
- Sample Load Lock
- > Automated Sample Alignment





### **M-2000<sup>®</sup>**





## **Ex Situ Applications**

Ellipsometry is Sensitive to:

- Layer thickness
- > Optical Constants
- Surface and Interfacial Roughness
- Composition / Crystallinity
- > Optical Anisotropy
- > Uniformity (over film area and depth)
- Any physical effect that induces changes in material optical properties



## **Semiconductor Industry**

- Dielectrics (oxides, nitrides, carbides)
- Polymers (Low-Dielectric constant)
- Polysilicon
- Multilayers (ONOPO, SOI, ...)
- Lithography Applications
  - Photoresists
  - Antireflective coatings
  - Photomasks
- Compound Semiconductors



## **Crystallinity: Polysilicon**

Optical constants depend strongly on crystallinity, which can vary with process conditions.





### Si<sub>3</sub>N<sub>4</sub> Film Thickness and Index Initial Modeling Attempts



### Si3N4 Film Thickness and Index Best Fit Model

After analysis, we found out film was deposited in two passes !



### **Organic Film on Si**

### Isotropic Model



#### MSE = 316.2





## **Spin-Cast Organic Film on Si**



### **Photoresists**

- Measure refractive index at each lithography line
  - 248 nm, 193 nm, 157 nm...





Monochromator before sample allows accurate optical characterization of resists in UV without exposing.



### Multilayer: Resist on ARC

Both layer thicknesses can be determined because of the DUV data where there is high optical contrast between layers.

2	Photoresist	6117.9 Å
1	i-line AR Coating	3107.7 Å
0	Silicon substrate	1 mm





### **Resist and ARC Optical Constants**

Similar Dispersion except at shorter wavelengths where both films become absorbing.



### **Phase Shifting Photomasks**

Complex material structures (index grading)





### High Sensitivity to Ultra-thin films

The "phase" information of Spectroscopic ellipsometry (not available from FTIR reflectance or absorptance) is highly sensitive to ultrathin films.

### Directly measure accurate Optical Constants

No Kramers-Kronig analysis with extrapolation required, as in FTIR.

### Non-destructive Characterization

Measurements do not require vacuum; can study liquid-solid interfaces, e.g. wet-etch, biological, or medical applications.

### No Baseline or Reference sample required

Samples smaller than the beam diameter can be measured because the entire beam does not need to be collected. Ellipsometric measurements are accurate and quantitative. FTIR reflectivity and absorbance measurements are relative.



### **Silicon Epitaxial Layers on Silicon**

### Drude equation used to model free carrier optical absorption

#### **Measured:**

- Epitaxial Si Layer Thickness (t<sub>epi</sub>) = 273nm
- Native Oxide Thickness (t<sub>ox</sub>) = 1.2nm
- Epitaxial Layer Resistivity ( $\rho_{epi}$ ) = 5.13  $\Omega$ -cm
- Substrate Resistivity ( $\rho_{sub}$ ) = 0.0175  $\Omega$ -cm

#### Model

2	native oxide (ir oscillator model)	t <sub>ox</sub>
1	silicon with free carriers	t <sub>epi</sub>
0	silicon with free carriers	0.6 mm

$$\boldsymbol{e}_{Drude} \left( E_{ph} = \boldsymbol{w} \right) = \frac{-2}{\boldsymbol{e}_{0} \boldsymbol{r} 10^{-2} \left( \boldsymbol{t} \cdot 10^{-15} E_{ph}^{2} + i E_{ph} \right)} \text{ and } \boldsymbol{r} = \frac{m^{*}}{Nq^{2} \boldsymbol{t}} = \frac{1}{q \boldsymbol{m} N}$$



## **Doping Concentration (resistivity)**

Dopants introduce free-carrier absorption in the Infrared.





### **THIN EPI-LAYER**

# Measure epi-layer thickness and substrate resistivity





### **Epi-silicon: Far-IR data & fit**



26

### **Ion-implanted doping profiles**

Implant-dose: 10<sup>15</sup> As-cm<sup>-2</sup> @ 80 keV

J.A. Woollam Co., Inc.



T.E. Tiwald, D.W. Thompson, J.A. Woollam, W. Paulson, and R. Hance, *Thin Solid Films*, **313-314** (1998) pp. 662-667.

SRP: Spreading Resistance Probe

## **Au Before and After Cleaning**

- Sample was removed for cleaning, and remounted for measurement
- > Note the high level of both precision and reproducibility in the data





### Optical Measurement of Phonon Structure in III-V Semiconductors

- IR-VASE<sup>®</sup> determined phonon spectra in agreement with published values
- > Data fit with simple Restrahlen model; without free-carrier effects
- RCE provides much better data than RAE





## In Situ Spectroscopic Ellipsometry

- In situ Spectroscopic Ellipsometry has been used in a wide variety of applications:
  - Sputter Deposition
  - Etching (RIE, ECR, ...)
  - Electrodeposition
  - e-Beam Evaporation
  - and more...

- Annealing
- MBE
- PVD
- CVD



## What Can We Measure In Situ?

- Substrate Temperature
- Substrate Surface Quality
- > Oxide Thickness and Desorption
- Interfacial regions
- Growth Rates
- Substrate and film optical constants
  - (without surface oxide)
- Alloy Composition
- Multi-layer Thickness



## **UNL Sputter Chamber**

Sputter chamber retrofit with optical ports for *insitu* ellipsometry.





Measure growth rate and optical constants for thin films.

# Real-time Thickness Prediction based on last 'n' points

Predict when to turn off process with high precision





## Hg1-xCdxTe (MCT) grown by MBE

### Purpose / Goals of *in situ* Ellipsometry:

Monitor Substrate Temperature before growth

- good quality MCT will grow only in a 10° temperature window

Monitor Substrate Surface Quality before growth

- the substrate is heated to desorb the oxide

### Monitor and Control the MCT Composition

- IR devices *require* a composition accuracy of ±0.001!



### **Composition Accuracy**

> 6 independent MCT growth runs (without control)

- post-deposition *in situ* ellipsometry analysis



35

**MCT Compositions Comparison** 

### Long Term Run-to-Run InGaAs Composition Accuracy

### Std. Dev. in SE composition error of ±0.002 achieved over a 6 month period (at ASU)



### **Generalized Ellipsometry...**

Does not assume zero off-diagonal components for the Jones matrix. Uses the following relationship...

$$\begin{bmatrix} p_{out} \\ s_{out} \end{bmatrix} = \begin{bmatrix} r_{pp} & r_{sp} \\ r_{ps} & r_{ss} \end{bmatrix} \cdot \begin{bmatrix} p_{in} \\ s_{in} \end{bmatrix}$$

- > Thus, a generalized sample is described by...
  - AnE  $\tan(\Psi) \cdot e^{i\Delta} = \frac{r_{pp}}{r_{ss}}$ - Aps  $\tan(\Psi_{ps}) \cdot e^{i\Delta_{ps}} = \frac{r_{ps}}{r_{pp}}$ - Asp  $\tan(\Psi_{sp}) \cdot e^{i\Delta_{sp}} = \frac{r_{sp}}{r_{ss}}$

J.A. Woollam Co., Inc.

### **Depolarization Measurements**

- > Requires AutoRetarder<sup>™</sup> or Rotating Compensator (e.g. M-2000<sup>®</sup>)
- Potential Applications
  - transparent substrates (back-side effects)
  - patterned samples
  - layer thickness non-uniformity
  - finite spectral bandwidth



### **Patterened Samples (depolarization)**



B. Johs, et al., "Overview of Variable Angle Spectroscopic Ellipsometry (VASE), Part II: Advanced Applications" SPIE Proc. Vol CR72, (1999) pp. 50-51.



39

### Conclusions

- 142 nm to 200 micron spectral range.
- Variable angle; focusing; mapping; monochromator or diode-based; polarization control: autoretarder.
- Ex situ applications:
  - oxides, poly-silicon, stacks, photoresists, surface contamination/cleaning, optical constants.
  - Advanced applications: graded layers, anisotropy, depolarization, patterned material.
- In situ monitor/control of:
  - Growth/etch, thickness, temperature, composition

