


HOx isotopes

Thomas F. Hanisco, Jason St. Clair, E. J. Moyer, F. N. Keutsch, D. S. Sayres, J. R. Spackman, R. Lockwood
E. M. Weinstock, James G. Anderson

Aura Validation Meeting
Pasadena, CA
March 3, 2005



HOx isotopes: Photolysis - Fluorescence detection of HDO/H₂O

Excimer Lamp Photolysis




$$h\nu = 8\text{W}$$

$$\lambda = 172\text{ nm}$$




OH and OD LIF

$$\lambda = 287\text{ nm}$$




Radical vs. Molecular Sampling


Molecular water exchanges with walls. OH and OD radicals are lost irreversibly



Preliminary Flight Results




050111



Residual Water During Ascent

Water source =
 4×10^4 ppmv s
 $\text{H}_2\text{O} \times 150 \text{ cm}^3/\text{s}$
flow = $6 \text{ cm}^3 \text{ H}_2\text{O}$
= 1.5×10^{20}

Inlet: $A = 100 \text{ cm}^2$,
1 ML = 1×10^{15}
 $\text{cm}^2 \rightarrow 1000 \text{ ML}$
 H_2O




Potential Water sources


- Nearest neighbors:
- Total water inlet
- Landing gear
- Fuselage



050111




20050111 Preliminary




In this stratospheric leg the measurement demonstrates a fast time response and good signal to noise


050111




Uncontaminated Profile



Contaminated Ascent




20 ppm Offset
Added to Both
H₂O and HDO




Summary

- Flight data high points:
 - Hoxotope worked as well in flight as in the lab
 - Fast time constant in H₂O and HDO sampling
 - Absence of unexplained artifacts
 - Good accuracy
 - Reasonable signal to noise (HDO \pm 250 pptv/4s)
- Post flight schedule:
 - Calibration: 5% (50 per mil)
 - Sensitivity: factor of 5 for moderate effort
- Thanks to NASA IIP, NASA WB57, Harvard Engineering


Laboratory Time Constant




Test flight 050108 Comparison to Lyman- α



Test Flight 050108 H₂O and HDO




Flight 041205




Motivation I: Water isotopes are valuable *in situ* tracers

- HDO condenses more readily than H₂O
- Rainout leads to HDO depletion
- Ice injection can make the stratosphere “Heavy”
- *In situ* water isotope measurements can offer a tracer for the condensation history of air parcels






Motivation II: In situ water isotope instruments require validation

- We expect instrument artifacts to contaminate water measurements.
 - Sampling
 - Optical
 - Software analysis
- Independent measurements can help identify artifacts.



Data acquisition

- OD and OH lines are scanned alternately (4 s) with background (2 s)
- OD and OH line positions are determined from real-time fits
- Post flight analysis:
 - Least squares fit of each line to get [OD] and [OH]
 - Multiply by cal factor to get [HDO] and [H₂O]



050111

