

... for a brighter future

Benchmarking of Advanced HEV's and PHEV's over a Wide Range of Ambient Temperatures

U.S. Department of Energy





A U.S. Department of Energy laboratory managed by UChicago Argonne, LLC Richard "Barney" Carlson, Dan Bocci, Ted Bohn, Mike Duoba Argonne National Laboratory Sponsored by Lee Slezak

DOE Merit Review 28 February, 2008





U.S. Department of Energy Energy Efficiency and Renewable Energy Bringing you a prosperous future where energy is clean, abundant, reliable, and affordable

"This presentation does not contain any proprietary or confidential information"


Over 15% of driving in the U.S. is at Sub-Freezing Temperatures

- On Road Testing is an Extension of the Benchmarking Activities
 - Sub-freezing ambient temperature conditions
 - High temperature conditions with real solar load
- FY07: Toyota Camry HEV and Ford Escape HEV
 - Fuel Economy
 - Battery Utilization and Characteristics
 - Powertrain Controls
- On-road testing conducted at four temperatures
 - -15°C, 0°C, 15°C, 30°C (winter, spring, summer)
 - Dynamometer testing conducted (22°C) for comparison to on-road testing
















Summary FY07: HEV Fuel Economy depends upon Battery performance

- Both vehicles
 - Battery power is very limited at low temperatures
 - Dramatically reduced fuel economy (nearly 2X) at cold temperature (from - 15°C to 20°C)
 - Minimal change in fuel economy at high temperatures (from 20°C to 35°C)
- Improved low temperature Battery power can improve fuel economy at low ambient temperatures
- If HEVs are dependent on battery performance, then PHEV's are even more dependent on battery performance
- This "Wide Temperature Benchmarking" study was chosen as one of the top VSATT projects of the year








FY08 Wide Temperature Range Benchmarking => PHEV's


- On road Testing of PHEV Conversions (Prius and Escape)
 - On Road evaluation at Argonne (ANL City Cycle)
 - Hymotion A123 Escape
 - Hymotion A123 Prius
 - Hymotion is provided A123 Ver.1 system
 - HybridsPlus 4.5kWhr Prius
 - Current road-block: inoperative due to current sensor module failure; replacement soon to be shipped from HybridsPlus Inc.
- Cold Chamber Dynamometer test facility
 - Collaboration with Environment Canada testing conducted in their cold Dyno
 - Hymotion A123 (Ver.2) Prius
 - Tests to be conducted (April May)
 - 22 °C (baseline)
 - -7 °C (same as cold CO test)
 - -18 °C (~0 °F)

\$200k (spent \$24k to date)






Hymotion Escape PHEV: Petroleum Displacement is Dependant on Battery Temperature






Hymotion Escape PHEV: Increasing Rate of Depletion with Increasing Battery Temperature





Benchmarking PHEV's at a Wide Temperature Range supports many DOE activities






Backup Slides




Hymotion Escape (-15 °C)






Hymotion Escape (-5 °C)






Hymotion Escape (5 °C)






Camry HEV: Fuel Economy is Reduced at low ambient temperature






Escape HEV On Road Testing at -10 °C Ambient






Fuel Economy Trends and Regenerative Braking Energy






Camry HEV Battery Voltage vs. Current over a wide Temperature Range





Escape HEV Battery Voltage vs. Current over a wide Temperature Range





Increased Battery Utilization, Increases Rate of Temperature Rise from Heating due to Internal Losses (I² R)

