


Kenneth Croes, Drew Pavlacky,
Dean Webster, Victoria Johnston Gelling, and Stuart Croll
Department of Coatings and Polymeric Materials
North Dakota State University

Luz Marina Calle and Wenyan Li
NASA Corrosion Technology Laboratory
Kennedy Space Center





SMART COATINGS: REACTIVE MICROCAPSULES CONTAINING CORROSION INHIBITORS

The authors would like to thank NASA KSC (cooperative agreement # NNNK06MB73A)
and for continuing support from ND Spacegrant.


CORROSION REACTIONS IN METALS



or



SMART COATINGS FOR CORROSION DETECTION




pH sensitive microcapsules

1. Corrosion indicators

2. Corrosion inhibitors

3. Healing agents

incorporated into coating



Smart coating will:

- Detect and indicate corrosion at its early stage.
- Release inhibitors to stop corrosion propagation.
- Heal mechanical damage to the coating.

MATERIALS



Microcapsules

Empty Oil Core/Empty Water Core



Water core with corrosion inhibitor Na_2MoO_4

Water core with corrosion inhibitor $\text{Ce}(\text{NO}_3)_3$

- ✘ Epon 828
- ✘ Amicure PACM-20



**First
Microcapsules
As-Received**



**Microcapsules in
Epoxy Coating**

ELECTROCHEMICAL EXPERIMENTAL

Electrolyte

- Dilute Harrison's solution (0.35% $(\text{NH}_4)_2\text{SO}_4$ and 0.05% NaCl)


Electrochemical cell

- Polyvinylchloride pipe with an inner diameter of 2.6 cm attached to the substrate using Marine Goop® adhesive.
- Platinum coated mesh counter electrode
- Saturated calomel reference electrode (SCE)


Gamry® Instrument's PC-4 or FAS1

- AC perturbation: 10 mV rms
- Frequency range: 100,000 Hz to 0.01 Hz


BLANK MICROCAPSULES




Na_2MoO_4 WATER CORE




Low Frequency Impedance







**OPEN CIRCUIT
POTENTIAL**





EPOXY AMINE CONTROL COATING





0 hours



10 hours



30 hours





EPOXY AMINE BLANK (WATER) MICROCAPSULES






0 hours

10 hours





30 hours







1 hour




3 hour




10 hour





15 hour




20 hour



35 hour




45 hour




Epoxy amine coating with 40% $\text{Ce}(\text{NO}_3)_3$ microcapsules at:

- 1 hour
- 3 hours
- 10 hours
- 15 hours
- 20 hours
- 25 hours
- 35 hours
- 45 hours


Ce(NO₃)₃ WATER CORE




1 Hour



1 Hour







35 Hours



35 Hours

Na_2MoO_4 WATER CORE



CONCLUSIONS

- Theory of microcapsules
 - Break down as a result of the products of cathodic reaction releasing green corrosion inhibitors, a dye, a pH indicator, or combinations
 - As capsules rupture the modulus of the coating system is reduced
- For Epoxy/Amine system
 - Decrease in Tg as more microcapsules were added
 - Decrease in gloss measurements as more microcapsules were added
 - Decrease in hardness as more microcapsules were added
 - Blank microcapsules showed to be thermally stable at about half the temperature as all the others with corrosion inhibitors
- Electrochemical
 - Corrosion inhibitor containing microcapsules do indicate corrosion protective properties
 - Blank microcapsules do not show any corrosion inhibitive properties

FUTURE STUDIES

- ✘ Varying the concentration of the microcapsules
- ✘ Incorporation of the microcapsules into other binder systems
- ✘ Long-term SVET studies to determine when the corrosion protective properties will fail
- ✘ Begin studies with primer/topcoat type system