



Multi-Purpose Plasma (MP²) Facility as a Steady State Divertor Simulator

B. J. Lee, K. Cho, A. England, T. Lho, J. Yoon, and plasma research team

Div. Of Plasma Application and Technology, NFRC, Korea

Abstract


Half of mirror device, HANBIT at National Fusion research Center has been modified since last year aiming at increasing the usability and applicability of the device toward wider fields; wave physics in linear, quiescent plasmas, space simulation and plasma application as well as a mirror physics. Ideas and direction of the renovated facility, MP2 and the future experimental program will be presented. It is suggested that a program to study the use of flowing molten salts for a tokamak liquid divertor be undertaken on the multipurpose plasma (MP2) device. Two possible candidates, flibe (LiF-BeF_2) and flinabe, (LiF-NaF-BeF_2) are briefly described and the reasons for this choice over liquid metals are discussed. A simple preliminary experiment is described.

Outlines

- Renovation for HANBIT to MP²(Multi-Purposed Plasma) Facility
- Assembly of MP²
- LaB6 Source for MP²
- Specification of MP²
- Molten Salts Project
- Future Studies on the Molten Salts of MP²

Structure of NFRC

- NFRC is the host institution of KSTAR, ITER-Korea, and Plasma physics & Engineering




- Plasma Physics related with Magnetic Fusion
--- KSTAR and ITER
- ~ 40 persons (30 Ph.Ds, 7 Masters, ~3 supporters)
+ collaborators

- Basic and Industry Applied Plasma Physics
--- MP2 facility and many plasma sources
- ~ 40 persons (10 Ph.Ds, 15 Masters, ~15 Engineers)
+ collaborators (from industry)


Hanbit Magnetic Mirror Device

Plasma Diagnostic Systems

- . H-alpha Monitor
- . Visible Spectrometer
- . VUV Spectrometer
- . Fast CCD Camera
- . Filter Scope
- . Micrometer Interferometer
- . Reflectometer
- . Electrostatic Probes
- . Magnetic Probes
- . Diamagnetic Probes
- . End Loss Analyzer
- . CX-NPA
- . Thomson Scattering System
- . Laser Induced Fluorescence



Control System
Data Acquisition
System




Plasma Heating Systems

- . 500 kW RF Power Amplifier
- . 100 kW RF Power Amplifier
- . 2 kW Klystron Amplifier(14.5 GHz)
- . 1.5 kW Klystron Amplifier(7.87 GHz, 7.67 GHz)
- . 5 kW Magnetron System(2.45 GHz)

Pre-ionization Devices

- . MPD Gun
- . Cathode Device




Magnet Power Supply
Vacuum Pumping
System
Utility

Brief history of Hanbit Device


- 1993. 1 Refurbished from the Tara Machine of MIT
- 1995. 6 First plasma on the Hanbit Device
- ~2000.9 First campaign : basic system development
- ~2006.6 Second campaign : high temperature plasma confinement physics study
 - RF plasma heating
 - MHD stability
 - discharge characteristics, etc
- 2006. 12 First stage assembling of the MP² Facility
(Cylindrical Plasma Generator)
- 2007. 1 First plasma on the MP² Facility

Facility for basic plasma physics research

Hanbit Device




MP² (Multi Purpose Plasma) Facility



Assembly of MP²


First stage assembling of MP²

(rev: 28-Aug-2006)




NOTE) → 챔버 이동 경로. → 자기장 코일 이동 경로. — Chamber to be made.


Total view of MP² Facility



Linear Machine Part in MP² Facility




Linear Machine Part in MP² Facility




Linear plasma device of MP² Facility

B-field profile for steady state operation



Source for Linear Machine Part in MP² Facility



Placement of LaB6 discs & Needed P/S's

The center LaB6 disc and the peripheral discs need to be independently heated to adjust plasma column size.


1. Heater Power Supply (P/S)

One P/S for carbon heater
to heat LaB6 **Center disc**
: DC P/S (30 V / 330 A)


Four P/S's for carbon (tungsten) heater
to heat LaB6 **Peripheral discs**
: DC P/S (40 V / 330 A) x 4EA

2. Discharge Power Supply



: DC P/S (250 V / 150 A) or
DC P/S (250 V / 80 A) x 2EA



First plasma on the MP² Facility



Specifications of MP²



Plasma Size (cm)	3.5
Chamber Diameter (m)	0.6(small) 1(large)
Chamber Length (m)	10
Magnetic Field (kG)	~ 1 kG
Plasma Source	Honeycomb-like LaB6 Cathode
Cathode Size (cm)	25
Discharge Type	Steady state DC discharge
Cathode Heating Power (kW)	up to 36kW
Discharge Power	250V - (1-100A)
Operating Gas	H ₂ , He, Ar
Operating Pressure (mTorr)	0.1-10
Plasma Density (cm ⁻³)	up to 10 ¹²
Electron Temperature (eV)	1-20 eV
Ion Temperature (eV)	0.1 Te
Location	Daejeon, Korea

Molten Salt experiments instead of liquid metals

- Molten salts have not yet been experimentally investigated in a divertor, the first wall, or blanket programs with plasma
- Molten salts have been experimentally investigated in two molten salt reactors at ORNL in the 1950's and 1960's
- Two possible molten salts as liquid wall materials study, FLiBe (LiF-BeF₂) and FLiNaBe(LiF-NaF-BeF₂)
- Two molten salts have similar physical properties except for melting point, The melting temperature of FLiBe is about 459°C and 380°C for FLiNaBe

Properties of Molten Salts

Typical Liquid Metal and Molten Salt Thermophysical Parameters

Properties	Units	FLiBe	Lithium
Composition	Mole %	66% LiF + 34% BeF ₂	100% Li
Melting Point	K	733	459
Operating Point	K	773	673
Density	kg/m ³	2036	490
Dynamic Viscosity	kg/m/s	0.015	4.02×10^{-4}
Kinematic Viscosity	m ² /s	7.37×10^{-6}	8.19×10^{-7}
Electrical Conductivity	S/m	155	3.19×10^6
Thermal Conductivity	W/m/K	1.06	50.4
Heat Capacity	J/kg/K	2380	4209
Surface Tension	N/m	0.2	0.366

ABDOU et al., NUCLEAR ENGINEERING AND TECHNOLOGY, VOL.37 NO.5 OCTOBER 2005


- Low thermal Conductivity
 - Low heat transfer to limit the peak surface temperature
 - For high heat transfer turbulence necessary
 - The turbulence potentially affected by the strong magnetic field

Properties of Molten Salts

- Low Electrical Conductivity ($\sim 10^2 \Omega^{-1} \text{ m}^{-1}$)
 - 4 order of magnitude smaller than typical liquid metals ($\sim 10^6 \Omega^{-1} \text{ m}^{-1}$)
 - No Strong MHD effects on surface flow.
 - Possibility of turbulent flow on the divertor surface.
 - But no vanishing of the electrical conductivity which is 30 times greater than sea water
- High Viscosity
 - about 10 times that of water.
- No Corrosive on Stainless Steel
 - Control of corrosion coming from fluorine and hydrogen-fluoride generation by plasma interaction.
- Low vapor Pressure, Less Evaporation

Use of Molten Salts in MP²

A Schematic of a molten salts exp.



- Study the Plasma-Molten salts interaction
- Concern on the possibility that the magnetic field might alter the flow
- Depression of the Fluorine generation
 - Study on the 'Redox' Agent, for example Be.
- Study the effects of turbulence on the heat transfer and flow.

Discussion

- A linear steady-state plasma device, which is a part of MP² facility, has been assembled as a divertor simulator
- As the name implies, the MP² will have various research scopes of plasma
- At the first stage of the research experiments on linear plasma device of MP² will be done for the dust plasma phenomena, mirror plasma physics, and PMI
- Research on the plasma-molten salts interaction will be the main topic in MP² once the device for it will be built
- The Reynold, Froude, Rayleigh and Nusselt numbers of molten salts will be varied to study the effects of turbulence on the heat transfer and turbulence flow on the divertor surface.