

**Geothermal Heat Pumps Product List**  
**List Current as of January 02, 2009**

Organization Name	Model Name	Product Type	Model Number
Advanced Geothermal Technology		DX with integrated WH	All Models beginning with GC
Bryant	GT-G	Closed Loop	Any model starting with 50YC (V/H/D) in sizes 015 to 060
Bryant	GT-G	Open Loop	Any model starting with 50YC (V/H/D) in sizes 015 to 070
Bryant	GT-GS	Closed Loop	Any model starting with 50YCS in sizes 018 to 060
Bryant	GT-GS	Open Loop	Any model starting with 50YCS in sizes 018 to 060
Bryant	GT-PG	Closed Loop	Any model starting with 50YE in sizes 018 to 070
Bryant	GT-PG	Open Loop	Any model starting with 50YE in sizes 018 to 070
Bryant	GT-PX	Closed Loop	Any model starting with 50YD in sizes 026 to 072
Bryant	GT-PX	Open Loop	Any model starting with 50YD in sizes 026 to 072
Bryant	GT-S	Closed Loop	Any model starting with 38WQS in sizes 018 to 060
Bryant	GT-S	Open Loop	Any model starting with 38WQS in sizes 018 to 060
Carrier Corporation	50vs Series	Closed Loop	VHC1
Carrier Corporation	50vs Series	Closed Loop	VHC2
Carrier Corporation	50vs Series	Closed Loop	VHC3
Carrier Corporation	50vs Series	Closed Loop	VHC4
Carrier Corporation	50vs Series	Closed Loop	VHC5
Carrier Corporation	50vs Series	Closed Loop	VHC6
Carrier Corporation	50vs Series	Closed Loop	VHC7
Carrier Corporation	50vs Series	Open Loop	VHC1
Carrier Corporation	50vs Series	Open Loop	VHC2
Carrier Corporation	50vs Series	Open Loop	VHC3
Carrier Corporation	50vs Series	Open Loop	VHC4
Carrier Corporation	50vs Series	Open Loop	VHC5
Carrier Corporation	50vs Series	Open Loop	VHC6
Carrier Corporation	50vs Series	Open Loop	VHC7

Organization Name	Model Name	Product Type	Model Number
Carrier Corporation	AQUAZONE	Closed Loop	Any model starting with 50PS in sizes 018 to 060, with ECM blower
Carrier Corporation	AQUAZONE	Closed Loop	Any model starting with 50PT in sizes 026 to 064
Carrier Corporation	AQUAZONE	Closed Loop	Any model starting with 50R(V/D/H)S in sizes 015 to 060
Carrier Corporation	AQUAZONE	Open Loop	Any model starting with 50PS in sizes 018 to 060, with ECM blower
Carrier Corporation	AQUAZONE	Open Loop	Any model starting with 50PS in sizes 018 to 070, with ECM blower
Carrier Corporation	AQUAZONE	Open Loop	Any model starting with 50PT in sizes 026 to 064
Carrier Corporation	AQUAZONE	Open Loop	Any model starting with 50R(V/D/H)S in sizes 015 to 070
Carrier Corporation	GT-G	Closed Loop	Any model starting with 50YC(V/H/D) in sizes 015 to 060
Carrier Corporation	GT-G	Open Loop	Any model starting with 50YC(V/H/D) in sizes 015 to 070
Carrier Corporation	GT-GS	Closed Loop	Any model starting with 50YCS in sizes 018 to 060
Carrier Corporation	GT-GS	Open Loop	Any model starting with 50YCS in sizes 018 to 060
Carrier Corporation	GT-PG	Closed Loop	Any model starting with 50YE in sizes 018to 070
Carrier Corporation	GT-PG	Open Loop	Any model starting with 50YE in sizes 018 to 070
Carrier Corporation	GT-PX	Closed Loop	Any model starting with 50YD in sizes 026 to 072
Carrier Corporation	GT-PX	Open Loop	Any model starting with 50YD in sizes 026 to 072
Carrier Corporation	GT-S	Closed Loop	Any model starting with 38WQS in sizes 018 to 060
Carrier Corporation	GT-S	Open Loop	Any model starting with 38WQS in sizes 018 to 060
ClimateMaster	Genesis	Closed Loop	all GSS series
ClimateMaster	Genesis	Closed Loop	all GSV/GSH and having "AGE" for 7th, 8th, & 9th digits
ClimateMaster	Genesis	Closed Loop	GSV/GSH015
ClimateMaster	Genesis	Closed Loop	GSV/GSH018; GSV/GSH024; GSV/GSH030; GSV/GSH036; GSV/GSH042; GSV/GSH048; GSV/GSH060
ClimateMaster	Genesis	Open Loop	all GSV/GSH and having "AGE" for 7th, 8th, & 9th digits
ClimateMaster	Genesis	Open Loop	all GSV/GSH series
ClimateMaster	Genesis	Open Loop	GSV/GSH015
ClimateMaster	Paradigm	Closed Loop	all PDW series

Organization Name	Model Name	Product Type	Model Number
ClimateMaster	Tranquility	Closed Loop	Any model starting with TSV018; TSD018; TSH018
ClimateMaster	Tranquility	Closed Loop	Any model starting with TSV024; TSD024; TSH024
ClimateMaster	Tranquility	Closed Loop	Any model starting with TSV030; TSD030; TSH030
ClimateMaster	Tranquility	Closed Loop	Any model starting with TSV036; TSD036; TSH036
ClimateMaster	Tranquility	Closed Loop	Any model starting with TSV042; TSD042; TSH042
ClimateMaster	Tranquility	Closed Loop	Any model starting with TSV048; TSD048; TSH048
ClimateMaster	Tranquility	Closed Loop	Any model starting with TSV060; TSD060; TSH060
ClimateMaster	Tranquility	Closed Loop	Any model starting with TSV070; TSD070; TSH070
ClimateMaster	Tranquility	Closed Loop	Any model starting with TTV026; TTD026; TTH026
ClimateMaster	Tranquility	Closed Loop	Any model starting with TTV038; TTD038; TTH038
ClimateMaster	Tranquility	Closed Loop	Any model starting with TTV049; TTD049; TTH049
ClimateMaster	Tranquility	Closed Loop	Any model starting with TTV064; TTD064; TTH064
ClimateMaster	Tranquility	Closed Loop	TSV006; TSH006
ClimateMaster	Tranquility	Closed Loop	TSV009; TSH009
ClimateMaster	Tranquility	Closed Loop	TSV012; TSH012
ClimateMaster	Tranquility	Closed Loop	TTS026
ClimateMaster	Tranquility	Closed Loop	TTS038
ClimateMaster	Tranquility	Closed Loop	TTS049
ClimateMaster	Tranquility	Closed Loop	TTS064
ClimateMaster	Tranquility	Closed Loop	TTV072; TTD072; TSH072
ClimateMaster	Tranquility	Open Loop	Any model starting with TSV018; TSD018; TSH018
ClimateMaster	Tranquility	Open Loop	Any model starting with TSV024; TSD024; TSH024
ClimateMaster	Tranquility	Open Loop	Any model starting with TSV030; TSD030; TSH030
ClimateMaster	Tranquility	Open Loop	Any model starting with TSV036; TSD036; TSH036
ClimateMaster	Tranquility	Open Loop	Any model starting with TSV042; TSD042; TSH042
ClimateMaster	Tranquility	Open Loop	Any model starting with TSV048; TSD048; TSH048
ClimateMaster	Tranquility	Open Loop	Any model starting with TSV060; TSD060; TSH060

Organization Name	Model Name	Product Type	Model Number
ClimateMaster	Tranquility	Open Loop	Any model starting with TTV026; TTD026; TTH026
ClimateMaster	Tranquility	Open Loop	Any model starting with TTV038; TTD038; TTH038
ClimateMaster	Tranquility	Open Loop	Any model starting with TTV049; TTD049; TTH049
ClimateMaster	Tranquility	Open Loop	Any model starting with TTV064; TTD064; TTH064
ClimateMaster	Tranquility	Open Loop	TSV006; TSH006
ClimateMaster	Tranquility	Open Loop	TSV009; TSH009
ClimateMaster	Tranquility	Open Loop	TSV012; TSH012
ClimateMaster	Tranquility	Open Loop	TTS026
ClimateMaster	Tranquility	Open Loop	TTS038
ClimateMaster	Tranquility	Open Loop	TTS049
ClimateMaster	Tranquility	Open Loop	TTS064
ClimateMaster	Tranquility	Open Loop	TTV072; TTD072; TSH072
ClimateMaster	VT	Closed Loop	all VT series
ClimateMaster		Open Loop	Any model starting with TSV070; TSD070; TSH070
Earth To Air Systems, LLC	TSDX	DX	TS18,24,27,30,36,42,48,54,60
ECONAR GeoSystems, LLC.	GeoSource 2000	Closed Loop	Any Model Starting with GH181
ECONAR GeoSystems, LLC.	GeoSource 2000	Closed Loop	Any Model Starting with GH231
ECONAR GeoSystems, LLC.	GeoSource 2000	Closed Loop	Any Model Starting with GH291
ECONAR GeoSystems, LLC.	GeoSource 2000	Closed Loop	Any Model Starting with GV181
ECONAR GeoSystems, LLC.	GeoSource 2000	Closed Loop	Any Model Starting with GV231
ECONAR GeoSystems, LLC.	GeoSource 2000	Closed Loop	Any Model Starting with GV291
ECONAR GeoSystems, LLC.	GeoSource 2000	Closed Loop	Any Model Starting with GV361
ECONAR GeoSystems, LLC.	GeoSource 2000	Open Loop	All Models Starting with GH231
ECONAR GeoSystems, LLC.	GeoSource 2000	Open Loop	All Models Starting with GV231
ECONAR GeoSystems, LLC.	GeoSource 2000	Open Loop	All Models Starting with GV361
ECONAR GeoSystems, LLC.	GeoSource DualTEK	Closed Loop	Any Model Starting with GV361
ECONAR GeoSystems, LLC.	GeoSource DualTEK	Open Loop	All Models Starting with GV361

Organization Name	Model Name	Product Type	Model Number
ECONAR GeoSystems, LLC.	GeoSource Vara	Closed Loop	Any Model Starting with GV361
ECONAR GeoSystems, LLC.	GeoSource Vara	Open Loop	All Models Starting with GV361
ECONAR GeoSystems, LLC.	Invision3	Closed Loop	Any Model Starting with Q14kW4T
ECONAR GeoSystems, LLC.	Invision3	Closed Loop	Any Model Starting with Q16kW6T
ECONAR GeoSystems, LLC.	Ultra Forced Air	Closed Loop	Any models starting with GV471
ECONAR GeoSystems, LLC.	Ultra Forced Air	Closed Loop	Any models starting with GV571
ECONAR GeoSystems, LLC.	Ultra Forced Air	Closed Loop	Any models starting with GV771
ECONAR GeoSystems, LLC.	Ultra Forced Air	Closed Loop	Any model starting with GV371
ECONAR GeoSystems, LLC.	Ultra Forced Air	Open Loop	Any models starting with GV471
ECONAR GeoSystems, LLC.	Ultra Forced Air	Open Loop	Any models starting with GV571
ECONAR GeoSystems, LLC.	Ultra Forced Air	Open Loop	Any models starting with GV771
ECONAR GeoSystems, LLC.	Ultra Forced Air	Open Loop	Any model starting with GV371
ECONAR GeoSystems, LLC.	Vara2Plus	Closed Loop	Any Model Starting with GH381
ECONAR GeoSystems, LLC.	Vara2Plus	Closed Loop	Any Model Starting with GH481
ECONAR GeoSystems, LLC.	Vara2Plus	Closed Loop	Any Model Starting with GH581
ECONAR GeoSystems, LLC.	Vara2Plus	Closed Loop	Any model starting with GH781
ECONAR GeoSystems, LLC.	Vara2Plus	Closed Loop	Any Model Starting with GV381
ECONAR GeoSystems, LLC.	Vara2Plus	Closed Loop	Any Model Starting with GV481
ECONAR GeoSystems, LLC.	Vara2Plus	Closed Loop	Any Model Starting with GV581
ECONAR GeoSystems, LLC.	Vara2Plus	Closed Loop	Any model starting with GV781
ECONAR GeoSystems, LLC.	Vara2Plus	Open Loop	All Models Starting with GH381
ECONAR GeoSystems, LLC.	Vara2Plus	Open Loop	All Models Starting with GH481
ECONAR GeoSystems, LLC.	Vara2Plus	Open Loop	All Models Starting with GH581
ECONAR GeoSystems, LLC.	Vara2Plus	Open Loop	All Models Starting with GV381
ECONAR GeoSystems, LLC.	Vara2Plus	Open Loop	All Models Starting with GV481
ECONAR GeoSystems, LLC.	Vara2Plus	Open Loop	All Models Starting with GV581
ECONAR GeoSystems, LLC.	Vara2Plus	Open Loop	Any model starting with GH781

Organization Name	Model Name	Product Type	Model Number
ECONAR GeoSystems, LLC.	Vara2Plus	Open Loop	Any model starting with GV781
ECR Technologies Incorporated	EarthlinkedTM	DX	All models beginning with HC
ECR Technologies Incorporated	EarthlinkedTM	DX	All models beginning with HW
ECR Technologies Incorporated	EarthlinkedTM	DX	All models beginning with SC
ECR Technologies Incorporated	EarthlinkedTM	DX	SC-024-1
ECR Technologies Incorporated	EarthlinkedTM	DX	SC-030-1
ECR Technologies Incorporated	EarthlinkedTM	DX	SC-036-1
ECR Technologies Incorporated	EarthlinkedTM	DX	SC-042-1
ECR Technologies Incorporated	EarthlinkedTM	DX	SC-048-1
ECR Technologies Incorporated	EarthlinkedTM	DX	SC-060-1
ECR Technologies Incorporated	EarthlinkedTM	DX	SC Series
ECR Technologies Incorporated	EarthlinkedTM	DX	SW Series
ECR Technologies Incorporated	EarthlinkedTM	DX with integrated WH	All models beginning with CWH
ECR Technologies Incorporated	EarthlinkedTM	DX with integrated WH	All models beginning with HCW
ECR Technologies Incorporated	EarthlinkedTM	DX with integrated WH	All models beginning with HWW
ECR Technologies Incorporated	EarthlinkedTM	DX with integrated WH	All models beginning with SCW
ECR Technologies Incorporated	EarthlinkedTM	DX with integrated WH	All models beginning with SD
ECR Technologies Incorporated	EarthlinkedTM	DX with integrated WH	All models beginning with SW
ECR Technologies Incorporated	EarthlinkedTM	DX with integrated WH	All models beginning with SWW
Enertech Manufacturing	GeoComfort Serenity GC Series, Single Capacity	Closed Loop	Any model starting with GC in sizes 018 to 060
Enertech Manufacturing	GeoComfort Serenity GC Series, Single Capacity	Open Loop	Any model starting with GC sizes 018 to 060
Enertech Manufacturing	GeoComfort Serenity GSC Series, Single Capacity-Split	Closed Loop	Any model starting with GSC in sizes 018 to 060
Enertech Manufacturing	GeoComfort Serenity GSC, Single Capacity-Split	Open Loop	Any model starting with GSC in sizes 018 to 072
Enertech Manufacturing	GeoComfort Serenity GS Series, Single Capacity	Closed Loop	Any model starting with GS in sizes in 018 to 072
Enertech Manufacturing	GeoComfort Serenity GS Series, Single Capacity	Open Loop	Any model starting with GS in sizes 018 to 072

Organization Name	Model Name	Product Type	Model Number
Enertech Manufacturing	GeoComfort Serenity GTC Series, Dual Capacity-Split	Closed Loop	Any model starting with GTC in sizes 024, 036, 048, 060
Enertech Manufacturing	GeoComfort Serenity GTC Series, Dual Capacity-Split	Open Loop	Any model starting with GTC in sizes 024, 036, 048, 060
Enertech Manufacturing	GeoComfort Serenity GT Series, Dual Capacity	Closed Loop	Any model starting with GT in sizes 024, 036, 048, 060
Enertech Manufacturing	GeoComfort Serenity GT Series, Dual Capacity	Open Loop	Any model starting with GT in sizes 024, 036, 048, 060
Enertech Manufacturing	GeoComfort Serenity GW Series, Dual Capacity	Closed Loop	Any model starting with GW in sizes 096 to 144
Enertech Manufacturing	GeoComfort Serenity GW Series, Single Capacity	Closed Loop	Any model starting with GW in sizes 024 to 072
Enertech Manufacturing	Hydron HC-Series Single Capacity	Closed Loop	Any model starting with HC in sizes 18, 24, 30, 36, 42, 48, 54, 60
Enertech Manufacturing	Hydron HC-Series Single Capacity	Open Loop	Any model starting with HC in sizes 18, 24, 30, 36, 42, 48, 54, 60
Enertech Manufacturing	Hydron Module H-Series Dual Capacity	Closed Loop	Any model starting with H in sizes 026, 038, 050, 062, 074, 096, 120
Enertech Manufacturing	Hydron Module H-Series Dual Capacity	Open Loop	Any model starting with H in sizes 026, 038, 050, 062, 074, 096, 120
Enertech Manufacturing	Hydron Module H-Series Dual Capacity-Split	Closed Loop	Any model starting with H in sizes 026C, 038C, 050C, 062C
Enertech Manufacturing	Hydron Module H-Series Dual Capacity-Split	Open Loop	Any model starting with H in sizes 026C, 038C, 050C, 062C
Enertech Manufacturing	Hydron Module H-Series Single Capacity	Closed Loop	Any model starting with H in sizes 018, 024, 030, 036, 042, 048, 060, 072
Enertech Manufacturing	Hydron Module H-Series Single Capacity	Open Loop	Any model starting with H in sizes 018, 024, 030, 036, 042, 048, 060, 072
Enertech Manufacturing	Hydron Module H-Series Single Capacity-Split	Closed Loop	Any model starting with H in sizes 018C, 024C, 030C, 036C, 042C, 048C, 060C
Enertech Manufacturing	Hydron Module H-Series Single Capacity-Split	Open Loop	Models with H in sizes, 018C, 024C, 030C, 036C, 042C, 048C, 060C, 072C
Enertech Manufacturing	Hydron Module W-Series Dual Capacity	Closed Loop	Any model starting with W in sizes 096 to 144
Enertech Manufacturing	Hydron Module W-Series Single Capacity	Closed Loop	Any model starting with W in sizes 024 to 072
FHP Manufacturing	Aquarius	Closed Loop	All AU Series Models CF, HZ, VT, CS
FHP Manufacturing	Aquarius	Closed Loop	CA Series Models 009, 012, 015
FHP Manufacturing	Aquarius	Closed Loop	EC Series Models CF, HZ, VT, 015, 018, 024

Organization Name	Model Name	Product Type	Model Number
FHP Manufacturing	Aquarius	Closed Loop	EC Series Models CF, HZ, VT, 030, 036, 042, 048, 051, 060, 061, 070
FHP Manufacturing	Aquarius	Closed Loop	EC Series Models CS 018, 024, 030, 036, 042, 048, 060, 070
FHP Manufacturing	Aquarius	Open Loop	All AU Series Models CF, HZ, VT, CS
FHP Manufacturing	Aquarius	Open Loop	CA Series Models 009, 012, 015
FHP Manufacturing	Aquarius	Open Loop	EC Series Models CF, HZ, VT, 007, 009, 012, 015, 018, 024
FHP Manufacturing	Aquarius	Open Loop	EC Series Models CF, HZ, VT, 030, 036, 042, 048, 051, 060, 061, 070
FHP Manufacturing	Aquarius	Open Loop	EC Series Models CS 018, 024, 030, 036, 042, 048, 060, 070
FHP Manufacturing	Aquarius 2	Closed Loop	All AP Series Models CF, HZ, VT
FHP Manufacturing	Aquarius 2	Open Loop	All AP Series Models CF, HZ, VT
FHP Manufacturing	Energy Miser	Closed Loop	EM Series Models CF, HZ, VT, 024, 028, 036, 051, 061
FHP Manufacturing	Energy Miser	Open Loop	EM Series Models CF, HZ, VT, 007, 009, 018, 024, 028
FHP Manufacturing	Energy Miser	Open Loop	EM Series Models CF, HZ, VT, 031, 036, 041, 042, 048, 051, 060, 061, 070
FHP Manufacturing	EnviroMiser	Closed Loop	ALL EV Series Models CF, HZ, VT
FHP Manufacturing	EnviroMiser	Closed Loop	EV Series Models CS 024, 030, 036, 042, 048, 060, 070
FHP Manufacturing	EnviroMiser	Open Loop	ALL EV Series Models CF, HZ, VT
FHP Manufacturing	EnviroMiser	Open Loop	EV Series Models CS 024, 030, 036, 042, 048, 060, 070
FHP Manufacturing	EnviroSaver	Closed Loop	ALL ES Series Models CF, HZ, VT
FHP Manufacturing	EnviroSaver	Closed Loop	ES Series Models CS 018, 024, 025, 030, 035, 036
FHP Manufacturing	EnviroSaver	Closed Loop	ES Series Models CS 042, 048, 049, 060, 061, 070, 071
FHP Manufacturing	EnviroSaver	Open Loop	ALL ES Series Models CF, HZ, VT
FHP Manufacturing	EnviroSaver	Open Loop	ES Series Models CS 018, 024, 025, 030, 035, 036
FHP Manufacturing	EnviroSaver	Open Loop	ES Series Models CS 042, 048, 049, 060, 061, 070, 071
FHP Manufacturing	Geo Saver	Closed Loop	All GS Series Models CF, HZ, VT
FHP Manufacturing	Geo Saver	Open Loop	All GS Series Models CF, HZ, VT
FHP Manufacturing	Geo Thermal	Closed Loop	All GT Series Models CF, HZ, VT



Organization Name	Model Name	Product Type	Model Number
FHP Manufacturing	Geo Thermal	Open Loop	All GT Series Models CF, HZ, VT
GeoMaster, LLC	GeoExcel	Closed Loop	All AU Models
GeoMaster, LLC	GeoExcel	Closed Loop	All ES models
GeoMaster, LLC	GeoExcel	Closed Loop	All GS Models
GeoMaster, LLC	GeoExcel	Closed Loop	EC048,051,061,096,150,151,180,181,210,240,242,360
GeoMaster, LLC	GeoExcel	Closed Loop	EM144, 180, 360
GeoMaster, LLC	GeoExcel	Closed Loop	EV018, 030, 036, 048
GeoMaster, LLC	GeoExcel	Closed Loop	GT010,018,024,030,036,042,048,054
GeoMaster, LLC	GeoExcel	Open Loop	All AU Models
GeoMaster, LLC	GeoExcel	Open Loop	All ES Models
GeoMaster, LLC	GeoExcel	Open Loop	All EV Models
GeoMaster, LLC	GeoExcel	Open Loop	All GS Models
GeoMaster, LLC	GeoExcel	Open Loop	All GT Models
GeoMaster, LLC	GeoExcel	Open Loop	CA009, 012
GeoMaster, LLC	GeoExcel	Open Loop	CS009, 012, 018
GeoMaster, LLC	GeoExcel	Open Loop	EC007,009, 012,024,030,036,042,048,051,060,061
GeoMaster, LLC	GeoExcel	Open Loop	EC070, 072, 096, 120, 150, 151, 180, 181, 210, 240, 242, 300, 360
GeoMaster, LLC	GeoExcel	Open Loop	EM007,009,018,024,028,031,036,042,048,060,070,072
GeoMaster, LLC	GeoExcel	Open Loop	EM096,120,144,150,168,170,180,210,240,300,360
Heat Controller Inc.		Closed Loop	HRV/HRH030B1
Heat Controller Inc.		Closed Loop	HRV/HRH036B1
Heat Controller Inc.		Closed Loop	HRV/HRH042B1
Heat Controller Inc.		Closed Loop	HRV/HRH048B1
Heat Controller Inc.		Closed Loop	HSS018
Heat Controller Inc.		Closed Loop	HSS024
Heat Controller Inc.		Closed Loop	HSS030
Heat Controller Inc.		Closed Loop	HSS036

Organization Name	Model Name	Product Type	Model Number
Heat Controller Inc.		Closed Loop	HSS042
Heat Controller Inc.		Closed Loop	HSS048
Heat Controller Inc.		Closed Loop	HSS060
Heat Controller Inc.		Closed Loop	HTS024 Full Load
Heat Controller Inc.		Closed Loop	HTS024 Part Load
Heat Controller Inc.		Closed Loop	HTS036 Full Load
Heat Controller Inc.		Closed Loop	HTS036 Part Load
Heat Controller Inc.		Closed Loop	HTS048 Full Load
Heat Controller Inc.		Closed Loop	HTS060 Full Load
Heat Controller Inc.		Closed Loop	HTS060 Part Load
Heat Controller Inc.		Closed Loop	HTV024 Full Load
Heat Controller Inc.		Closed Loop	HTV024 Part Load
Heat Controller Inc.		Closed Loop	HTV036 Full Load
Heat Controller Inc.		Closed Loop	HTV036 Part Load
Heat Controller Inc.		Closed Loop	HTV048 Full Load
Heat Controller Inc.		Closed Loop	HTV048 Part Load
Heat Controller Inc.		Closed Loop	HTV060 Full Load
Heat Controller Inc.		Closed Loop	HTV060 Part Load
Heat Controller Inc.		Open Loop	HRV/HRH030B1
Heat Controller Inc.		Open Loop	HRV/HRH036B1
Heat Controller Inc.		Open Loop	HRV/HRH042B1
Heat Controller Inc.		Open Loop	HRV/HRH048B1
Heat Controller Inc.		Open Loop	HSS018
Heat Controller Inc.		Open Loop	HSS024
Heat Controller Inc.		Open Loop	HSS030
Heat Controller Inc.		Open Loop	HSS036
Heat Controller Inc.		Open Loop	HSS042

Organization Name	Model Name	Product Type	Model Number
Heat Controller Inc.		Open Loop	HSS048
Heat Controller Inc.		Open Loop	HSS060
Heat Controller Inc.		Open Loop	HTS024 Full Load
Heat Controller Inc.		Open Loop	HTS024 Part Load
Heat Controller Inc.		Open Loop	HTS036 Full Load
Heat Controller Inc.		Open Loop	HTS036 Part Load
Heat Controller Inc.		Open Loop	HTS048 Full Load
Heat Controller Inc.		Open Loop	HTS048 Part Load
Heat Controller Inc.		Open Loop	HTS060 Full Load
Heat Controller Inc.		Open Loop	HTS060 Part Load
Heat Controller Inc.		Open Loop	HTV024 Full Load
Heat Controller Inc.		Open Loop	HTV024 Part Load
Heat Controller Inc.		Open Loop	HTV036 Full Load
Heat Controller Inc.		Open Loop	HTV036 Part Load
Heat Controller Inc.		Open Loop	HTV048 Full Load
Heat Controller Inc.		Open Loop	HTV048 Part Load
Heat Controller Inc.		Open Loop	HTV060 Full Load
Heat Controller Inc.		Open Loop	HTV060 Part Load
Hydro Delta Corporation	Extended Range	Closed Loop	HE1V 010, 015, 018, 026, 036, 046, 054, 068, 093, 120
Hydro Delta Corporation	Extended Range	Closed Loop with integrated WH	HE1V 010, 015, 018, 026, 036, 046, 054, 068, 093, 120
Hydro Delta Corporation	Extended Range	Open Loop	HE1V 010, 015, 018, 026, 036, 046, 054, 068, 093, 120
Hydro Delta Corporation	Extended Range	Open Loop with integrated WH	HE1V 010, 015, 018, 026, 036, 046, 054, 068, 093, 120
Hydro Delta Corporation	Horizon	Closed Loop	HR1H 006, 010, 015, 020, 027, 032, 038, 044, 054, 068
Hydro Delta Corporation	Horizon	Closed Loop with integrated WH	HR1H 006, 010, 015, 020, 027, 032, 038, 044, 054, 068
Hydro Delta Corporation	Horizon	Open Loop	HR1H 006, 010, 015, 020, 027, 032, 038, 044, 054, 068
Hydro Delta Corporation	Horizon	Open Loop with integrated WH	HR1H 006, 010, 015, 020, 027, 032, 038, 044, 054, 068
Hydro Delta Corporation	HydroHeat Extended Range	Closed Loop	HE2V 011, 016, 019, 028, 037, 047, 057, 069, 094, 121

Organization Name	Model Name	Product Type	Model Number
Hydro Delta Corporation	HydroHeat Extended Range	Closed Loop with integrated WH	HE2V 011, 016, 019, 028, 037, 047, 057, 069, 094, 121
Hydro Delta Corporation	HydroHeat Extended Range	Open Loop	HE2V 011, 016, 019, 028, 037, 047, 057, 069, 094, 121
Hydro Delta Corporation	HydroHeat Extended Range	Open Loop with integrated WH	HE2V 011, 016, 019, 028, 037, 047, 057, 069, 094, 121
Hydro Delta Corporation	HydroHeat Horizon	Closed Loop	HR2H 006, 011, 016, 021, 028, 033, 039, 047, 057, 069
Hydro Delta Corporation	HydroHeat Horizon	Closed Loop with integrated WH	HR2H 006, 011, 016, 021, 028, 033, 039, 047, 057, 069
Hydro Delta Corporation	HydroHeat Horizon	Open Loop	HR2H 006, 011, 016, 021, 028, 033, 039, 047, 057, 069
Hydro Delta Corporation	HydroHeat Horizon	Open Loop with integrated WH	HR2H 006, 011, 016, 021, 028, 033, 039, 047, 057, 069
Hydro Delta Corporation	HydroHeat Mega-Tek TS	Closed Loop	MT3V 062; MT4V 043, 056, 061; SP4C 043, 056, 061
Hydro Delta Corporation	HydroHeat Mega-Tek TS	Closed Loop with integrated WH	MT3V 062; MT4V 043, 056, 061; SP4C 043, 056, 061
Hydro Delta Corporation	HydroHeat Mega-Tek TS	Open Loop	MT3V 062; MT4V 043, 056, 061; SP4C 043, 056, 061
Hydro Delta Corporation	HydroHeat Mega-Tek TS	Open Loop with integrated WH	MT3V 062; MT4V 043, 056, 061; SP4C 043, 056, 061
Hydro Delta Corporation	HydroHeat Split	Closed Loop	SP2C 019, 028, 037, 047, 057, 069
Hydro Delta Corporation	HydroHeat Split	Closed Loop with integrated WH	SP2C 019, 028, 037, 047, 057, 069
Hydro Delta Corporation	Magnum	Closed Loop	MG1X 037, 048, 068, 093, 120
Hydro Delta Corporation	Magnum	Closed Loop with integrated WH	MG1X 037, 048, 068, 093, 120
Hydro Delta Corporation	Magnum	Open Loop	MG1X 037, 048, 068, 093, 120
Hydro Delta Corporation	Magnum	Open Loop with integrated WH	MG1X 037, 048, 068, 093, 120
Hydro Delta Corporation	Mega-Tek	Closed Loop	MT1V 040, 055, 062
Hydro Delta Corporation	Mega-Tek	Closed Loop with integrated WH	MT1V 040, 055, 062
Hydro Delta Corporation	Mega-Tek	Open Loop	MT1V 040, 055, 062
Hydro Delta Corporation	Mega-Tek	Open Loop with integrated WH	MT1V 040, 055, 062
Hydro Delta Corporation	Split	Closed Loop	SP1C 018, 026, 036, 046, 054, 068
Hydro Delta Corporation	Split	Closed Loop with integrated WH	SP1C 018, 026, 036, 046, 054, 068
Hydro Delta Corporation	Split	Open Loop	SP1C 018, 026, 036, 046, 054, 068
Hydro Delta Corporation	Split	Open Loop with integrated WH	SP1C 018, 026, 036, 046, 054, 068
McQuay International	Enfinity	Closed Loop	CCW-007,019,024,030,036,042,048,060
McQuay International	Enfinity	Closed Loop	FCW-019,024,030,036,042,048,06

Organization Name	Model Name	Product Type	Model Number
McQuay International	Enfinity	Open Loop	CCW-007,009.012.019,024,030,036,042,048,060
McQuay International	Enfinity	Open Loop	FCW-007,009,.012.019,024,030,036,042,048,06
Northern Heat Pump Inc.	XTERRA	Closed Loop	RTHE30 (P)
Northern Heat Pump Inc.	XTERRA	Closed Loop	RTHE51 (P)
Northern Heat Pump Inc.	XTERRA	Closed Loop	RTHE60 (P)
Northern Heat Pump Inc.	XTERRA	Closed Loop	RTVE30 (P)
Northern Heat Pump Inc.	XTERRA	Closed Loop	RTVE40 (P)
Northern Heat Pump Inc.	XTERRA	Closed Loop	RTVE51 (P)
Northern Heat Pump Inc.	XTERRA	Closed Loop	RTVE60
Northern Heat Pump Inc.	XTERRA	Closed Loop	RTVE60 (P)
Rittling	VSN Series	Closed Loop	VHCH1
Rittling	VSN Series	Closed Loop	VHCH2
Rittling	VSN Series	Closed Loop	VHCH3
Rittling	VSN Series	Closed Loop	VHCH4
Rittling	VSN Series	Closed Loop	VHCH5
Rittling	VSN Series	Closed Loop	VHCH6
Rittling	VSN Series	Closed Loop	VHCH7
Rittling	VSN Series	Open Loop	VHCH1
Rittling	VSN Series	Open Loop	VHCH2
Rittling	VSN Series	Open Loop	VHCH3
Rittling	VSN Series	Open Loop	VHCH4
Rittling	VSN Series	Open Loop	VHCH5
Rittling	VSN Series	Open Loop	VHCH6
Rittling	VSN Series	Open Loop	VHCH7
Trane and American Standard Heating and Air Conditioning	Commercial High Efficiency	Closed Loop with integrated WH	WPHF
Trane and American Standard Heating and Air Conditioning	Commercial High Efficiency	Closed Loop with integrated WH	WPVJ

Organization Name	Model Name	Product Type	Model Number
Trane and American Standard Heating and Air Conditioning	GEHE	Closed Loop	GEHE072
Trane and American Standard Heating and Air Conditioning	GEHE	Closed Loop	GEHE090
Trane and American Standard Heating and Air Conditioning	GEHE	Closed Loop	GEHE150
Trane and American Standard Heating and Air Conditioning	GEHE	Closed Loop	GEHE180
Trane and American Standard Heating and Air Conditioning	GEHE	Open Loop	GEHE072
Trane and American Standard Heating and Air Conditioning	GEHE	Open Loop	GEHE090
Trane and American Standard Heating and Air Conditioning	GEHE	Open Loop	GEHE120
Trane and American Standard Heating and Air Conditioning	GEHE	Open Loop	GEHE150
Trane and American Standard Heating and Air Conditioning	GEHE	Open Loop	GEHE180
Trane and American Standard Heating and Air Conditioning	GEVE	Closed Loop	GEVE072
Trane and American Standard Heating and Air Conditioning	GEVE	Closed Loop	GEVE090
Trane and American Standard Heating and Air Conditioning	GEVE	Closed Loop	GEVE120
Trane and American Standard Heating and Air Conditioning	GEVE	Closed Loop	GEVE150
Trane and American Standard Heating and Air Conditioning	GEVE	Closed Loop	GEVE180
Trane and American Standard Heating and Air Conditioning	GEVE	Closed Loop	GEVE240
Trane and American Standard Heating and Air Conditioning	GEVE	Closed Loop	GEVE300
Trane and American Standard Heating and Air Conditioning	GEVE	Open Loop	GEVE072
Trane and American Standard Heating and Air Conditioning	GEVE	Open Loop	GEVE090
Trane and American Standard Heating and Air Conditioning	GEVE	Open Loop	GEVE120
Trane and American Standard Heating and Air Conditioning	GEVE	Open Loop	GEVE150

Organization Name	Model Name	Product Type	Model Number
Trane and American Standard Heating and Air Conditioning	GEVE	Open Loop	GEVE180
Trane and American Standard Heating and Air Conditioning	GEVE	Open Loop	GEVE240
Trane and American Standard Heating and Air Conditioning	GEVE	Open Loop	GEVE300
Trane and American Standard Heating and Air Conditioning	WPVJ	Closed Loop	WPVJ030
Trane and American Standard Heating and Air Conditioning	WPVJ	Closed Loop	WPVJ036
Trane and American Standard Heating and Air Conditioning	WPVJ	Closed Loop	WPVJ042
Trane and American Standard Heating and Air Conditioning	WPVJ	Closed Loop	WPVJ048
Trane and American Standard Heating and Air Conditioning	WPVJ	Closed Loop	WPVJ060
WaterFurnace International, Incorporated	Envision	Closed Loop	ND_026
WaterFurnace International, Incorporated	Envision	Closed Loop	ND_038
WaterFurnace International, Incorporated	Envision	Closed Loop	ND_049
WaterFurnace International, Incorporated	Envision	Closed Loop	ND_064
WaterFurnace International, Incorporated	Envision	Closed Loop	ND_072
WaterFurnace International, Incorporated	Envision	Closed Loop	NS_022
WaterFurnace International, Incorporated	Envision	Closed Loop	NS_030
WaterFurnace International, Incorporated	Envision	Closed Loop	NS_036
WaterFurnace International, Incorporated	Envision	Closed Loop	NS_042
WaterFurnace International, Incorporated	Envision	Closed Loop	NS_048
WaterFurnace International, Incorporated	Envision	Closed Loop	NS_060
WaterFurnace International, Incorporated	Envision	Closed Loop	NS_070

Organization Name	Model Name	Product Type	Model Number
WaterFurnace International, Incorporated	Envision	Open Loop	ND_026
WaterFurnace International, Incorporated	Envision	Open Loop	ND_038
WaterFurnace International, Incorporated	Envision	Open Loop	ND_049
WaterFurnace International, Incorporated	Envision	Open Loop	ND_064
WaterFurnace International, Incorporated	Envision	Open Loop	NS_022
WaterFurnace International, Incorporated	Envision	Open Loop	NS_030
WaterFurnace International, Incorporated	Envision	Open Loop	NS_036
WaterFurnace International, Incorporated	Envision	Open Loop	NS_042
WaterFurnace International, Incorporated	Envision	Open Loop	NS_048
WaterFurnace International, Incorporated	Envision	Open Loop	NS_060
WaterFurnace International, Incorporated	Envision	Open Loop	NS_070
WaterFurnace International, Incorporated	Envision Console	Closed Loop	NC_09
WaterFurnace International, Incorporated	Envision Console	Closed Loop	NC_12
WaterFurnace International, Incorporated	Envision Console	Closed Loop	NC_15
WaterFurnace International, Incorporated	Envision Console	Open Loop	NC_12
WaterFurnace International, Incorporated	Envision Console	Open Loop	NC_15
WaterFurnace International, Incorporated	Envision Console	Open Loop	NC_18
WaterFurnace International, Incorporated	E Series	Closed Loop	E024
WaterFurnace International, Incorporated	E Series	Closed Loop	E030
WaterFurnace International, Incorporated	E Series	Closed Loop	E035



Organization Name	Model Name	Product Type	Model Number
WaterFurnace International, Incorporated	E Series	Closed Loop	E036 Dual Capacity
WaterFurnace International, Incorporated	E Series	Closed Loop	E040
WaterFurnace International, Incorporated	E Series	Closed Loop	E047
WaterFurnace International, Incorporated	E Series	Closed Loop	E048 Dual Capacity
WaterFurnace International, Incorporated	E Series	Closed Loop	E058
WaterFurnace International, Incorporated	E Series	Closed Loop	E060 Dual Capacity
WaterFurnace International, Incorporated	E Series	Closed Loop	E066
WaterFurnace International, Incorporated	E Series	Closed Loop	E072 Dual Capacity
WaterFurnace International, Incorporated	ES Series	Closed Loop	ES024
WaterFurnace International, Incorporated	ES Series	Closed Loop	ES030
WaterFurnace International, Incorporated	ES Series	Closed Loop	ES036 Dual Capacity
WaterFurnace International, Incorporated	ES Series	Closed Loop	ES048 Dual Capacity
WaterFurnace International, Incorporated	ES Series	Closed Loop	ES060
WaterFurnace International, Incorporated	ES Series	Closed Loop	ES072 Dual Capacity
WaterFurnace International, Incorporated	EZ Series	Closed Loop	EZ024
WaterFurnace International, Incorporated	EZ Series	Closed Loop	EZ030
WaterFurnace International, Incorporated	EZ Series	Closed Loop	EZ035
WaterFurnace International, Incorporated	EZ Series	Closed Loop	EZ036
WaterFurnace International, Incorporated	EZ Series	Closed Loop	EZ040
WaterFurnace International, Incorporated	EZ Series	Closed Loop	EZ047

Organization Name	Model Name	Product Type	Model Number
WaterFurnace International, Incorporated	EZ Series	Closed Loop	EZ048 Dual Capacity
WaterFurnace International, Incorporated	EZ Series	Closed Loop	EZ058
WaterFurnace International, Incorporated	EZ Series	Closed Loop	EZ060 Dual Capacity
WaterFurnace International, Incorporated	EZ Series	Closed Loop	EZ072 Dual Capacity
WaterFurnace International, Incorporated	Premier	Closed Loop	P010
WaterFurnace International, Incorporated	Premier	Closed Loop	P019
WaterFurnace International, Incorporated	Premier	Closed Loop	P022
WaterFurnace International, Incorporated	Premier	Closed Loop	P028
WaterFurnace International, Incorporated	Premier	Closed Loop	P034
WaterFurnace International, Incorporated	Premier	Closed Loop	P040
WaterFurnace International, Incorporated	Premier	Closed Loop	P046
WaterFurnace International, Incorporated	Premier	Closed Loop	P056
WaterFurnace International, Incorporated	Premier	Closed Loop	P066
WaterFurnace International, Incorporated	Premier	Closed Loop	P013
WaterFurnace International, Incorporated	Synergy	Open Loop	RTV046*1
WaterFurnace International, Incorporated	Synergy	Open Loop	RTV056*1
WaterFurnace International, Incorporated	Synergy	Open Loop	RTV066*1
WaterFurnace International, Incorporated	Synergy3	Closed Loop	RTV046
WaterFurnace International, Incorporated	Synergy3	Closed Loop	RTV056
WaterFurnace International, Incorporated	Synergy3	Closed Loop	RTV066

Organization Name	Model Name	Product Type	Model Number
WaterFurnace International, Incorporated	Synergy 3D	Closed Loop	SDV038
WaterFurnace International, Incorporated	Synergy 3D	Closed Loop	SDV049
WaterFurnace International, Incorporated	Synergy 3D	Closed Loop	SDV064
WaterFurnace International, Incorporated	Synergy 3D	Closed Loop	SDV072
WaterFurnace International, Incorporated	Synergy 3D	Open Loop	SDV038
WaterFurnace International, Incorporated	Synergy 3D	Open Loop	SDV049
WaterFurnace International, Incorporated	Synergy 3D	Open Loop	SDV064
WaterFurnace International, Incorporated	Synergy 3D	Open Loop	SDV072