



## DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RUNWAY 13R: Turn right heading 160° as soon as possible after take-off but not later than 0.6 DME outbound on the I-DPX localizer southeast course, then intercept and climb via the CVE R-139 and expect vector to appropriate route. Maintain 5000 feet and expect filed altitude 10 minutes after departure.

ARDMORE TRANSITION (KRUMM4.ADM): From over FUZ VORTAC via FUZ R-348 to LOWGN INT, then via ADM R-179 to ADM VORTAC.

BLECO TRANSITION (KRUMM4.BLECO): (ATC assigned.) From over FUZ VORTAC via FUZ R-360 to BLECO INT.

EAKER TRANSITION (KRUMM4.EAKER): (For aircraft inbound to the TULSA terminal area.) From over FUZ VORTAC via FUZ R-012 to EAKER INT.

GRABE TRANSITION (KRUMM4.GRABE): (ATC assigned.) From over FUZ VORTAC via FUZ R-012 to GRABE INT.

MCALESTER TRANSITION (KRUMM4.MLC): (For all aircraft overflying the MLC VORTAC or intercepting J105.) From over FUZ VORTAC via FUZ R-022 to TIKYS INT, then via MLC R-206 to MLC VORTAC.

OKMULGEE TRANSITION (KRUMM4.OKM): (For all aircraft overflying OKM VOR/DME proceeding via J181 to BDF to destinations in the Chicago terminal area and north.) From over FUZ VORTAC via FUZ R-012 to EAKER INT, then via OKM R-196 to OKM VOR/DME.

ROLLS TRANSITION (KRUMM4.ROLLS): (For all aircraft proceeding northwest bound via J52.) From over FUZ VORTAC via FUZ R-348 to LOWGN INT, then via ADM R-179 to ADM VORTAC, then via ADM R-303 to ROLLS INT.

TULSA TRANSITION (KRUMM4.TUL): (For all aircraft overflying TUL VORTAC.) From over FUZ VORTAC via FUZ R-360 to ZEMMA INT, then via TUL R-201 to TUL VORTAC.

WILL ROGERS TRANSITION (KRUMM4.IRW): (For all aircraft inbound to the Oklahoma City area or overflying IRW VORTAC.) From over FUZ VORTAC via FUZ R-360 to ZEMMA INT, then via IRW R-145 to IRW VORTAC.

ZEMMA TRANSITION (KRUMM4.ZEMMA): (ATC assigned.) From over FUZ VORTAC via FUZ R-360 to ZEMMA INT.

SC-2, 12 FEB 2009 to 12 MAR 2009

SC-2, 12 FEB 2009 to 12 MAR 2009